

# Vigilohm IM400 series

## Insulation Monitoring Device

### User Manual

07/2018



---

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2018 Schneider Electric. All Rights Reserved.

---

# Table of Contents

---



	<b>Safety Information</b> .....	5
	<b>About the Book</b> .....	7
<b>Chapter 1</b>	<b>Introduction</b> .....	9
	Introduction .....	10
	Physical Description .....	12
	Accessories .....	13
<b>Chapter 2</b>	<b>Installation</b> .....	17
	Safety Measures .....	18
	Dimensions .....	20
	Flush Mounting and Dismantling .....	21
	Mounting on and Dismantling from a Grid .....	24
	Connection .....	25
	Typical Applications .....	27
<b>Chapter 3</b>	<b>Functions</b> .....	31
	R and C Measurement .....	32
	Configuration and Accuracy Zones by Application .....	33
	Monitoring the System Insulation .....	37
	Operation on Systems with a Voltage Greater Than 480 Vac/dc .....	47
	Operation on Systems with Medium Voltage .....	48
	Insulation Fault Location .....	49
	Injection Inhibition Input and Exclusion Management .....	50
	Self-Test .....	56
<b>Chapter 4</b>	<b>Human Machine Interface</b> .....	57
	Vigilohm IM400 Menu Structure .....	58
	Navigating the Interface .....	60
	Status Screens .....	62
	Special Status Screens .....	64
	Modifying Parameters .....	66
	Clock .....	68
	Insulation Fault Log .....	69
	Trend Screens .....	70
<b>Chapter 5</b>	<b>Communication via Modbus RS-485</b> .....	71
	Configuring RS-485 Communication Port .....	72
	Table of Modbus Functions .....	73
	Modbus Registers Tables .....	74
<b>Chapter 6</b>	<b>Maintenance and Troubleshooting</b> .....	85
	Safety Precautions .....	86
	Commissioning .....	87
	Maintenance and Troubleshooting .....	88
<b>Chapter 7</b>	<b>Functional Safety Standards Compliance</b> .....	91
	Safety Standards Compliance Requirements .....	92
	Product Installation and Wiring .....	93
	Commissioning for Functional Safety Standards Compliance .....	95
<b>Chapter 8</b>	<b>Specifications</b> .....	97
	Specifications .....	97
<b>Glossary</b>	.....	101

---



## Important Information

### NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

### **DANGER**

**DANGER** indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

### **WARNING**

**WARNING** indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

### **CAUTION**

**CAUTION** indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

### **NOTICE**

**NOTICE** is used to address practices not related to physical injury.

### PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

### FCC Notice

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designated to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

---

# About the Book



## At a Glance

### Document Scope

This manual is intended for use by designers, panel builders, installers, system integrators, and maintenance technicians who use ungrounded power systems (IT) with insulation monitoring devices (IMDs).

### Validity Note

The Vigilohm IM400 is used to monitor lines to earth insulation of ungrounded power systems. This includes industrial and marine electrical systems, infrastructures, and power generation systems such as photovoltaic and wind turbines. Thanks to the adaptive multi-frequency injection signal, the Vigilohm IM400 is suitable for power and control circuits that contain switching power electronics (speed drives, motor starters, inverters, thyristors) and DC components. The Vigilohm IM400 allows automatic and manual fault location.

This user manual is applicable to all models of the "Vigilohm IM400" line including the, IMD-IM400C (fully coated product for harsh environments), IMDIM400L (24...48 Vdc supply voltage), IMDIM400THR (For monitoring medium voltage application) and IMDIM400LTHR (24...48 Vdc supply voltage / For monitoring medium voltage application). All IM400 models are referred to as "Vigilohm IM400" or "IM400" unless specified otherwise. All differences between the models, such as a feature specific to one model, are indicated with the appropriate model number or description.

### Related Documents

Title of Documentation	Reference Number
Instruction Sheet: Vigilohm IM400, IM400L, IM400C Insulation Monitoring Device Vigilohm IM400THR, IM400LTHR Insulation Monitoring Device	S1B9007601 QGH8990201
Vigilohm Catalog	PLSED310020EN PLSED310020FR
The IT earthing system: a solution to improve industrial electrical network availability - Application guide	PLSED110006EN
Système de liaison à la terre IT - Une solution pour améliorer la disponibilité des réseaux électriques dans l'industrie - Guide d'application	PLSED110006FR
System earthings in LV Les schémas des liaisons à la terre en BT (régimes du neutre)	Cahier technique n° 172
The IT system earthing (unearthed neutral) in LV Le schéma IT (à neutre isolé) des liaisons à la terre en BT	Cahier technique n° 178

You can download these technical publications and other technical information from our website at <https://www.schneider-electric.com/en/download>



---

# Chapter 1

## Introduction

---

### What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Introduction	10
Physical Description	12
Accessories	13

## Introduction

### Using Ungrounded IT System to Improve Power Availability and Reduce Risk of Fire

Continuity of service is an essential operational requirement for power systems, as is ensuring the protection of people and property.

The "ungrounded" IT system is the best option for ensuring continuity of service. Even after an initial insulation fault has occurred, the installation can continue to function without posing any danger to people or equipment. However, the faulty circuit must be detected and repaired before a second fault occurs. The fact that the IT system can tolerate an initial fault means that maintenance operations can be improved and carried out safely and without any pressure.

### Monitor Insulation Resistance (R)

Standards IEC 60364 and IEC 61557-8 stipulate that the installation must be ungrounded when the IT system is used. In the event of only one ground or earth fault, the fault current is very low and interruption is unnecessary. However, given that a second fault could potentially cause the circuit breaker to trip, an insulation monitoring device has to be installed to indicate an initial fault. This device must trigger an audible and/or a visual signal.

By constantly monitoring the insulation resistance, you can keep track of the system quality, which is a form of preventive maintenance.

### Monitor the Leakage Rate (C)

According to standard IEC 60364-4-41, the following conditions ensure protection against indirect contact in AC power systems:

$$R_A \times I_d \leq 50 \text{ V}$$

Where:

- $R_A$  is the resistance value of the grounding connection of the equipment exposed-conductive-parts.
- $I_d$  is the ground fault current, in A.
- 50 V is the maximal acceptable voltage for indirect contacts.

In ungrounded, 3-phase, AC power systems, fault current  $I_d$  is  $I_d = 2\pi \times F \times C \times V$ .

Where:

- $C$  is the earth leakage capacitance of the power system.
- $F$  is the frequency of the power system.
- $V$  is the phase to neutral voltage.

$$2\pi \times F \times V \times C \times R_A \leq 50 \text{ V}$$

Thus it is necessary to monitor the earth leakage capacitance C and to have a low-resistance value of grounding connections.

For more information, see *Cahier technique n°178*.

### Functions of Vigilohm IM400 Insulation Monitoring Device

Vigilohm IM400 is a digital insulation monitoring device (IMD) for low-voltage and medium voltage systems with isolated neutral IT. Vigilohm IM400 can be used to monitor the insulation of a system and signal any insulation faults as soon as they occur.

Vigilohm IM400 applies several patented combinations of low-frequency AC voltage between the system and ground to provide accurate insulation monitoring in complex applications. The insulation is then assessed on the basis of the current value returned. This method is used for all types of systems: AC, DC, mixed, with rectifiers, with variable speed drives, with inverters, and so on.

Vigilohm IM400 offers the following functions:

- Insulation resistance display (R)
- Detection of insulation faults in accordance with a configurable threshold
- Display of earth leakage capacitance (C) and associated impedance ( $Z_c$ )<sup>1</sup>
- Communication via the Modbus RS-485 protocol
- Injection inhibition via logic input
- Insulation fault log
- Trending of the insulation resistance (R) from last hour to last year
- Quick setup of the monitoring parameters according to the applications


- Compatibility with voltage adaptor ( $U_{max} = 1,700 \text{ Vac Ph-Ph}$  or  $U_{max} = 1,200 \text{ Vdc}$ )
- Compatibility with P1N ground adaptor and voltage transformer ( $U_{max} = 33 \text{ kVac}$ )<sup>2</sup>

<sup>1</sup> Applicable for IM400/IM400C/IM400L

<sup>2</sup> Applicable for IM400THR/IM400LTHR

## Physical Description

### Physical Description



- A Display
- B Contextual menu buttons
- C **MENU** button
- D Red indicator light for Vigilohm IM400 product status
- E Yellow indicator light for Modbus communication indication
- F Green indicator light for correct insulation indication
- G White indicator light for preventive insulation alarm
- H Yellow indicator light for insulation alarm
- I **ESC** button for returning to previous menu or canceling a parameter entry
- J Vigilohm product catalog number
- K Vigilohm serial number
- L Auxiliary power supply terminal block
- M Injection terminal block
- N Insulation alarm relay terminal block
- O Preventive insulation alarm relay terminal block
- P Modbus RS-485 terminal block
- Q Injection inhibition input terminal block

## Accessories

### Presentation

The following accessories might be required depending on the type of installation on which Vigilohm IM400 is installed:

- A Cardew C surge limiter
- A ZX impedance
- A voltage/ground adaptor
- A voltage transformer

Below is a list of accessories for the Vigilohm devices:



Accessory	Catalog number
250 V Cardew C surge limiter	50170
440 V Cardew C surge limiter	50171
660 V Cardew C surge limiter <sup>(1)</sup>	50172
1,000 V Cardew C surge limiter <sup>(1)</sup>	50183
Cardew C base <sup>(2)</sup>	50169
ZX impedance	50159
IM400-1700 voltage adaptor <sup>(3)</sup>	<ul style="list-style-type: none"> <li>• IMD-IM400-1700</li> <li>• IMD-IM400-1700C</li> </ul>
PHT1000 voltage adaptor <sup>(4)</sup>	50248
IM400VA2 voltage adaptor <sup>(3)</sup>	IMD-IM400VA2
P1N ground adaptor	PHA6326700
Voltage transformer	Refer note
<p><b>(1)</b> Compatible with the Vigilohm IM400 when used with voltage adaptor IM400-1700 or PHT1000 or IM400VA2.  <b>(2)</b> Compatible with all Cardew C catalog numbers.  <b>(3)</b> For power systems with <math>U_{max} &gt; 480</math> Vac Ph-Neutral, or <math>U_{max} &gt; 830</math> Vac Ph-Ph, or <math>U_{max} &gt; 480</math> Vdc without insulation fault locator.  <b>(4)</b> For power systems with <math>U_{max} &gt; 480</math> Vac Ph-Neutral, or <math>U_{max} &gt; 830</math> Vac Ph-Ph, or <math>U_{max} &gt; 480</math> Vdc with insulation fault locator.</p>	

#### NOTE:



- IM400VA2 and IM400-1700C voltage adaptor are applicable for IM400C. IM400VA2 voltage adaptor is applicable for Photovoltaic mode.
- P1N ground adaptor is applicable for IM400THR/IM400LTHR.
- For information regarding automatic and mobile insulation fault locating accessories, refer to the relevant section ([see page 49](#)).
- Voltage transformers must be selected appropriately depending on system voltage. Refer to the Schneider Electric Medium Voltage Transformer catalogue.

### Cardew C Surge Limiter

<b>Function</b>	<p>The Cardew C is used when the insulation monitoring device is connected to the secondary of an MV/LV transformer (according to the rules and conventions that apply in various countries). It ensures protection of low-voltage (LV) installation against over-voltage. It is connected to the transformer secondary.</p> <p>The Cardew C may be used on the following systems:</p> <ul style="list-style-type: none"> <li>• <math>U &lt; 1000</math> Vac</li> <li>• <math>U &lt; 300</math> Vdc</li> </ul>			
<b>Selection table</b>	<b>Un: Nominal Phase-to-Phase Voltage of AC System</b>		<b>Ui: Arcing Voltage</b>	<b>Type of Cardew C</b>
	Accessible neutral	Not accessible neutral		
	$U \leq 380$ V	$U \leq 220$ V	$400$ V $< U_i \leq 750$ V	250 V
	$380$ V $< U \leq 660$ V	$220$ V $< U \leq 380$ V	$700$ V $< U_i \leq 1,100$ V	440 V
	$660$ V $< U \leq 1,000$ V	$380$ V $< U \leq 660$ V	$1,100$ V $< U_i \leq 1,600$ V	660 V
$1,000$ V $< U \leq 1,560$ V	$660$ V $< U \leq 1,000$ V	$1,600$ V $< U_i \leq 2,400$ V	1,000 V	

<p><b>Dimensions</b></p>	<p>mm in.</p> 
<p><b>Mounting</b></p>	<ul style="list-style-type: none"> <li>• Cardew C mounted directly on busbars</li> <li>• Mounting with plate-mounted base</li> </ul>
<p><b>Connection</b></p>	








**ZX Impedance**

<p><b>Function</b></p>	<p>The ZX impedance creates an installation with an impedance grounded neutral system (1500 Ω at 50 Hz).          The ZX remains connected during insulation fault locating at 2.5 Hz:</p> <ul style="list-style-type: none"> <li>• 1,500 Ω at 50 Hz</li> <li>• 1 M Ω at 2.5 Hz</li> </ul> <p>The ZX impedance must be used on systems with <math>U \leq 500</math> Vac.</p>
<p><b>Dimensions</b></p>	<p>mm in.</p> 
<p><b>Mounting</b></p>	<p>On mounting plate</p>
<p><b>Connection</b></p>	

**Voltage/Ground Adaptors**

The optional voltage/ground adaptors are:

- IM400-1700
- PHT1000
- IM400VA2
- P1N

<p><b>Function</b></p>	<p>The IM400-1700, PHT1000, and IM400VA2 voltage adaptors can be used to connect a Vigilohm IM400 to voltage systems higher than 480 Vac L-L. The wire connecting IM400-1700, IM400VA2, or P1N to Vigilohm IM400 has to have the same voltage rating as the monitored network. The compatibility of voltage adaptors with insulation fault location is as follows:</p> <ul style="list-style-type: none"> <li>● The IM400-1700, IM400VA2, and P1N voltage adaptors is not compatible with insulation fault location.</li> <li>● The PHT1000 voltage adaptor is compatible with insulation fault location.</li> </ul> <p>The P1N ground adaptor must be connected with the system for the operation of IM400THR/IM400LTHR.</p>			
<p><b>Dimensions</b></p>	<p><b>IM400-1700</b></p> 	<p><b>PHT1000</b></p> 	<p><b>IM400VA2</b></p> 	<p><b>P1N</b></p> 
<p><b>Mounting</b></p>	<p>On DIN rail</p>	<p>On mounting plate</p>	<p>On DIN rail and mounting plate</p>	<p>On mounting plate</p>
<p><b>Connection</b></p>	<p>Monitored network <i>(see page 25)</i></p> 	<p>Monitored network <i>(see page 25)</i></p> 	<p>Monitored network <i>(see page 25)</i></p> 	<p>Monitored network <i>(see page 25)</i></p>
<p>(1) Voltage adaptor connected to a phase (2) Voltage adaptor connected to neutral</p>				

**S3 Subassembly (Retrofit)**

Insulation alarm thresholds of the Vigilohm IM400 has to be set higher than 2 kΩ to take into account internal impedance of the no longer commercialized S3 subassembly.



---

# Chapter 2

## Installation

---

### What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Safety Measures	18
Dimensions	20
Flush Mounting and Dismantling	21
Mounting on and Dismantling from a Grid	24
Connection	25
Typical Applications	27

## Safety Measures

### Specific Hazard Associated with Insulation Monitoring Devices (IMDs)

In the case of almost all electric and electronic devices, the device power supply is the root cause of electrical hazards. The hazard can be mostly reduced by disconnecting the power supply.

This is not the case with insulation monitoring devices, which are connected to the system via the injection wire.

So this connection must be broken before carrying out any kind of work on the product.

 <b>DANGER</b>
<b>HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH</b>
<ul style="list-style-type: none"><li>• Before carrying out work of any kind, disconnect the Vigilohm IM400 from the monitored system by disconnecting wiring terminals 1, 2, and 3 of injection terminal block. Disconnect all the power supplies running to the Vigilohm and the equipment on which it is installed.</li><li>• Always use a correctly calibrated voltage tester to check that the injection wire and power supply have been properly disconnected.</li></ul>
<b>Failure to follow these instructions will result in death or serious injury.</b>

### Specific Hazard Associated with IM400-1700 Voltage Adaptor

 <b>DANGER</b>
<b>HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH</b>
Connect the ground wiring terminal (4) on the IM400-1700 voltage adaptor to a protective earth ground (PE) conductor.
<b>Failure to follow these instructions will result in death or serious injury.</b>

### Specific Hazard Associated with IM400VA2 Voltage Adaptor

 <b>DANGER</b>
<b>HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH</b>
Connect the ground wiring terminal (4) on the IM400VA2 voltage adaptor to a protective earth ground (PE) conductor.
<b>Failure to follow these instructions will result in death or serious injury.</b>

### Specific Hazard Associated with IMDIM400L

<b>NOTICE</b>
<b>HAZARD OF PRODUCT DAMAGE</b>
Ensure that maximum supply voltage is 48Vdc.
<b>Failure to follow these instructions can result in equipment damage.</b>

### Specific Hazard Associated with P1N Ground Adaptor

 <b>DANGER</b>
<b>HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH</b>
Connect the ground wiring terminal on the P1N ground adaptor to a protective earth ground (PE) conductor.
<b>Failure to follow these instructions will result in death or serious injury.</b>

## Other Safety Measures

Carefully read through the safety measures described below. You are always required to implement them fully before attempting to install, repair, or service electrical equipment.

### **DANGER**

#### **HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

- Wear suitable personal protective equipment and follow the currently applicable electrical safety instructions.
- This equipment may only be installed by qualified electricians who have read all the relevant information.
- NEVER work alone.
- Before performing visual inspections, tests, or maintenance on this equipment, disconnect all sources of electric power. Assume that all circuits are live until they have been completely de-energized, tested, and tagged. Pay particular attention to the design of the power system. Consider all power supply sources, particularly the potential for backfeed.
- Before closing protective covers and doors, carefully inspect the work area to ensure that no tools or objects have been left inside the equipment.
- Take care when removing or replacing panels. Take special care to ensure that they do not come into contact with live busbars. To minimize the risk of injuries, do not tamper with the panels.
- The successful operation of this equipment depends upon proper handling, installation, and operation. Failure to follow basic installation procedures can lead to personal injury as well as damage to electrical equipment or other property.
- NEVER shunt an external fuse/circuit breaker.
- The Vigilohm must be installed in a suitable electrical cabinet.

**Failure to follow these instructions will result in death or serious injury.**

A dielectric test (Hi-Pot) or a Megger test on a device installed in the power system monitored by the Vigilohm IM400 can damage the Vigilohm IM400.

### ***NOTICE***


#### **HAZARD OF PRODUCT DAMAGE**

Before performing a dielectric test (Hi-Pot) or a Megger test, disconnect the Vigilohm input and output wires.

**Failure to follow these instructions can result in equipment damage.**

## Dimensions

### Vigilohm IM400 Dimensions



## ⚠ CAUTION


### CUTTING HAZARD

Trim the edges of the cut-out plates to remove any jagged edges.

**Failure to follow these instructions can result in injury or equipment damage.**

### Constraints for Flush Mounting

Observe the correct distances between devices.



## Flush Mounting and Dismantling

### Presentation

Vigilohm IM400 can be attached to any flat, rigid vertical support using the spring clips supplied. The device must not be tilted following installation.

To free up useful space for control gear, you can attach the Vigilohm to the front panel of the floor-standing or wall-mounted enclosure.


For USA and Canada, Vigilohm IM400 mounting is to be open type only.








### Installing

Before attaching the Vigilohm, check the following:

- The mounting plate must have a thickness of between 0.8 mm (0.03 in) and 3.2 mm (0.12 in).
- A rectangle measuring 148 x 112 mm (5.83 x 4.41 in) must be cut out from the plate so the device can be installed.
- No terminal blocks are connected to the unit.

To install the Vigilohm, proceed as follows:




Step	Action
1	<p>Insert the Vigilohm in the cut-out in the mounting plate by tilting the device forward slightly.</p> 

Step	Action				
2	<p>Depending on the thickness of the mounting plate, clip the spring clips into the mounting slots on the device as described below. First, clip the spring clip at the top.</p>				
	<table border="1"> <tr> <td> <p>If the mounting plate thickness (X) is:  <math>0.8 \text{ mm} \leq X \leq 2 \text{ mm}</math>  <math>(0.03 \text{ in} \leq X \leq 0.08 \text{ in})</math></p> </td> <td> <p>The mounting slot to be used is:</p>  </td> </tr> <tr> <td> <p>If the mounting plate thickness (X) is:  <math>2 \text{ mm} &lt; X \leq 3.2 \text{ mm}</math>  <math>(0.08 \text{ in} \leq X \leq 0.12 \text{ in})</math></p> </td> <td> <p>The mounting slot to be used is:</p>  </td> </tr> </table>	<p>If the mounting plate thickness (X) is:  <math>0.8 \text{ mm} \leq X \leq 2 \text{ mm}</math>  <math>(0.03 \text{ in} \leq X \leq 0.08 \text{ in})</math></p>	<p>The mounting slot to be used is:</p> 	<p>If the mounting plate thickness (X) is:  <math>2 \text{ mm} &lt; X \leq 3.2 \text{ mm}</math>  <math>(0.08 \text{ in} \leq X \leq 0.12 \text{ in})</math></p>	<p>The mounting slot to be used is:</p> 
<p>If the mounting plate thickness (X) is:  <math>0.8 \text{ mm} \leq X \leq 2 \text{ mm}</math>  <math>(0.03 \text{ in} \leq X \leq 0.08 \text{ in})</math></p>	<p>The mounting slot to be used is:</p> 				
<p>If the mounting plate thickness (X) is:  <math>2 \text{ mm} &lt; X \leq 3.2 \text{ mm}</math>  <math>(0.08 \text{ in} \leq X \leq 0.12 \text{ in})</math></p>	<p>The mounting slot to be used is:</p> 				
3	<p>Clip the 2 spring clips on the device sides then the 2 spring clips at the device bottom.</p> 				
4	<p>Wire up and insert the terminal blocks as shown in the relevant wiring diagram (<i>see page 25</i>).</p>				

### Removing

To remove the Vigilohm from a mounting plate, proceed as follows:

Step	Action
1	<p>Disconnect the terminal blocks from the Vigilohm.</p>

Step	Action
2	<p data-bbox="483 203 1444 282">Deal with each of the spring clips as follows: insert the blade of a screwdriver between the spring clip and the device. Then use the screwdriver as a lever to release the spring clip. Start releasing the spring clips at the top and bottom of the device.</p> 
3	<p data-bbox="483 710 919 739">Release the 2 spring clips at the device sides.</p> 
4	<p data-bbox="483 1151 831 1180">Remove the Vigilohm from the plate.</p> 

## Mounting on and Dismantling from a Grid

### Presentation



To install the Vigilohm on a grid using fixing brackets (reference 01199 Prisma catalog) or equivalent. The device must not be tilted following installation.

When mounting the device or dismantling it using clamps, you can keep the terminal blocks connected and wired up, or you can remove them and keep them to hand.

For USA and Canada, Vigilohm IM400 mounting is to be open type only.

### Mounting

To install the Vigilohm on a grid using fixing brackets, proceed as follows:

Step	Action
1	<p>Position the fixing brackets on the Vigilohm and tighten the screws and washers as described below (tightening torque: 1.2 N.m (8.85 lb-in.).</p> 
2	<p>Attach the assembly to the grid using clamps.</p> 


### Removing

To remove the Vigilohm from a grid, unscrew the clamps from the grid to release the device.

## Connection

### Connection Diagram

The diagram below illustrates how to connect the Vigilohm to a single-phase or three-phase 3- or 4-wire power system, or a DC power system.




The relay operating mode (failsafe or standard) is controlled via the HMI of the Vigilohm device or with Modbus communication.

**NOTE:** Circuit breakers (reference MGN61334 or equivalent) can be used to replace listed fuses.

### Connection in medium voltage

**NOTE:** This connection diagram is applicable for IM400THR/IM400LTHR.

Voltage transformers and P1N ground adaptor are used to connect IM400THR to systems with voltages rated up to 33kVac. Voltage transformers should be selected appropriately depending on system voltage. Refer to the Schneider Electric medium voltage transformer catalogue.



**NOTE:** Ensure that maximum voltage between pins 2 and 3 of P1N ground adaptor is less than 250 Vac, 400 Vdc.  
 The Load Resistance '1R' of the Voltage Transformer is calculated based on its characteristics. Refer to the calculation notes on [www.schneider-electric.com/IM400THR](http://www.schneider-electric.com/IM400THR) for more information.

**Connection Characteristics**

All the Vigilohm IM400 wiring terminals have identical wiring capabilities.

The table shows the characteristics of the cables that can be used to connect the wiring terminals:

Stripped Length	Cross-Section Area	Tightening Torque	Type of Screwdriver
7 mm (0.27 in)	0.2...2.5 mm <sup>2</sup> (AWG 24...14)	0.8 N•m (7 lb-in)	Flat, ≤ 3 mm (≤ 0.10 in)

Cross-section area and voltage rating of wires must be suitable to the load current and to the voltage to which it is connected. The following characteristics need to be considered:

- Auxiliary power supply consumption: 25 VA / 10 Ω
- Current flowing to the monitoring network wiring terminal: less than 20 mA
- Current flowing to the injection inhibition wiring terminal: 5 mA
- Current flowing to the insulation alarm and to the preventive insulation alarm wiring terminals depends on the power rating of the insulation alarm indicator.

## Typical Applications

### Presentation

The following section presents five insulation monitoring applications for an IT power system:


- One application with a standalone Vigilohm IM400
- One application with Vigilohm IM400 where the insulation alarm and preventive insulation alarm outputs are sent to a supervisor
- One application with Vigilohm IM400 where the insulation alarm and preventive insulation alarm outputs are sent to a supervisor, and locating the insulation fault is done using an XD301 or XD312 automatic fault locator and an XRM mobile fault locator
- One application with a Vigilohm IM400 connected to a communication network
- One application with a Vigilohm IM400 connected to a communication network, and locating the insulation fault is done using an XD308C insulation fault locator

### Monitoring the Insulation of an IT Power System with a Standalone Vigilohm IM400

An IT power system is a system involving the use of a transformer whose neutral is not grounded.

The insulation is monitored by one Vigilohm IM400 with the following characteristics:


- IM400 is powered by the system that it monitors.
- IM400 is connected to neutral (or to one phase) and ground.
- The insulation fault threshold level is the only IM400 setting to be set up. The preventive insulation alarm can be set up.
- Vigilohm IM400 has a single relay output to control a light or a buzzer.



### Monitoring the Insulation of an IT Power System with a Vigilohm IM400 Where the Insulation Alarm Is Sent to a Supervisor

The insulation is monitored by a Vigilohm IM400 whose insulation alarm and preventive insulation alarm outputs are connected to an available input on a networked device (a PLC, for example). This device is itself connected to a supervisor via a communication network.

As far as this architecture is concerned, the restriction is that only the insulation fault and preventive insulation alarm information is available at supervisor level.




**Monitoring the Insulation of an IT Power System with a Vigilohm IM400 and Insulation Fault Location Where the Insulation Alarm Is Sent to a Supervisor**

The insulation is monitored by a Vigilohm IM400 whose insulation alarm and preventive insulation alarm outputs are connected to an available input on a networked device (a PLC, for example). This device is itself connected to a supervisor via a communication network.

Locating the insulation fault is done using XD301 or XD312 devices. The XD301 or XD312 output relay is connected to an available input on a networked device.

The XRM mobile insulation fault locator is used to locate accurately the area where the insulation fault is.


As far as this architecture is concerned, the restriction is that only the insulation fault information and group of faulty feeder are available at supervisor level.



### Monitoring the Insulation of an IT Power System with a Vigilohm IM400 Connected to a Communication Network

When the Vigilohm IM400 insulation monitoring device is linked to the supervisor via a Modbus connection, the following actions are supported:

- Display:
  - Product status
  - Status of the insulation alarm (active, not active, acknowledged) and status of the preventive insulation alarm
  - Details of the last 30 time-tagged events
  - Values for R and C to create tables or curves for monitoring these values over variable periods
- Configuring the product remotely: all the settings can be accessed remotely, except for the Modbus parameters (**Address, Auto Config, Baudrate, and Parity**).



The Ethernet gateway can be an EGX series or Com'X series, for example.


### Monitoring the Insulation of an IT Power System with a Vigilohm IM400 Connected to a Communication Network and Insulation Fault Location

When the Vigilohm IM400 insulation monitoring device is linked to the supervisor via a Modbus connection, the following actions are supported:

- Display:
  - Product status
  - Status of the insulation alarm (active, not active, acknowledged) and status of the preventive insulation alarm
  - Details of the last 30 time-tagged events
  - Values for R and C to create tables or curves for monitoring these values over variable periods
- Configuring the product remotely: all the settings can be accessed remotely, except for the Modbus parameters.

Using the XD308C insulation fault location device in addition with the XLI300 communication interface allows also the supervisor to monitor remotely all the feeders and so to report precisely any insulation fault location.

The XRM mobile insulation fault locator is used to locate accurately the area where the insulation fault is.



---

# Chapter 3

## Functions

---

### What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
R and C Measurement	32
Configuration and Accuracy Zones by Application	33
Monitoring the System Insulation	37
Operation on Systems with a Voltage Greater Than 480 Vac/dc	47
Operation on Systems with Medium Voltage	48
Insulation Fault Location	49
Injection Inhibition Input and Exclusion Management	50
Self-Test	56

## R and C Measurement

### Insulation Measurements

Vigilohm IM400 is designed to monitor the IT power system insulation.

IM400/IM400C/IM400L is designed:

- To measure:
  - The insulation resistance  $R$  ( $\Omega$ ) continuously,
  - The insulation capacitance  $C$ , which is the leakage capacitance of the distribution system to ground ( $\mu\text{F}$ ),
- To calculate the impedance  $Z_c$  ( $\text{k}\Omega$ ) associated with  $C$ .

IM400THR/IM400LTHR is designed to measure only the insulation resistance  $R$  ( $\Omega$ ) continuously.

### Effect of Leakage Capacitance on the Measurement Accuracy of R

The leakage capacitance ( $C$ ) creates a leakage path for the measurement signal and reduces the level of the useful signal that flows through the insulation resistance ( $R$ ).

The Vigilohm IM400 injects a signal with low frequencies and includes high-performance integration algorithms. It makes it compatible with large power systems that have a high value of leakage capacitance.

For other IMDs using switching mode measurement signals, the leakage capacitance ( $C$ ) has an impact on the measurement accuracy of the insulation resistance ( $R$ ).

The Vigilohm IM400 correctly operates in:

- power systems with leakage capacitance up to 500  $\mu\text{F}$
- photovoltaic systems with leakage capacitance up to 5,500  $\mu\text{F}$  with IM400VA2 voltage adaptor, and 2,000  $\mu\text{F}$  with IM400-1700 voltage adaptor

### Effect of Frequency Disturbances on the Measurement Accuracy of R

Switching mode power electronic devices apply residual voltages between the power system and ground. These voltages may interfere with IMDs measurements.

The Vigilohm IM400 injects an adaptive multi-frequency measurement signal that makes it operate out of the disturbance range. This measurement signal is combined with efficient integration algorithms to allow accurate measurements regardless of the frequency disturbances.

## Configuration and Accuracy Zones by Application

### Configuration by Application

Vigilohm IM400 is designed and tested to be compliant with different applications:

- Power circuits: industrial or marine applications that contain power loads and power electronics such as speed drives, inverters, or rectifiers.
- Control circuits: auxiliary control circuits used to drive power systems. These circuits contain sensitive loads such as PLCs, IOs, or sensors.
- Photovoltaic systems: large photovoltaic power generation systems. This application is characterized by high DC rated voltage (up to 1,500 V) and high system leakage capacitance (up to 5,500  $\mu$ F with IM400VA2 voltage adaptor, and up to 2,000  $\mu$ F with IM400-1700 voltage adaptor)
- Medium voltage system: Applications up to 33 kV with compatible Schneider Electric voltage transformer.

### Applications

To optimize the measurement performances of Vigilohm IM400 according to the application, set the application parameter by selecting **Menu** → **Settings** → **Network** → **App.**

Set the **App.** parameter value depending on the type of application on which Vigilohm IM400 is installed:

Parameter value	Application
<b>Power C.</b> (factory setting)	Power circuits
<b>Control C.</b>	Control circuits
<b>Photovolt</b>	Photovoltaic
<b>THR</b>	Medium voltage system

**NOTE:** The Photovoltaic mode is applicable for IM400C.

For IM400THR/IM400LTHR, the **App.** parameter value is fixed to **THR**.

The measurement parameters accessible in the **Network** menu are automatically preset depending on the application:

- **Filtering**
- **Locating**
- **V. Adapt**
- **Frequency**
- **Injection**

There is no need to configure these parameters in typical conditions.

The table shows the preset values of the measurement parameters according to the application parameter:

Preset values	Application parameters			
	Power C.	Control C.	Photovolt	THR
<b>Filtering</b>	Medium	Medium	Medium	20S
<b>Locating</b>	ON	ON	OFF	-
<b>V. Adapt</b>	None	None	HV1700C	None
<b>Frequency</b>	50 Hz	DC	DC	-
<b>Injection</b>	Std	Min	Max	60V

**NOTE:** Selecting **HV1700** parameter for **V. Adapt** selects IM400-1700 as the voltage adaptor.

Selecting **HV1700C** parameter for **V. Adapt** selects IM400-1700C as the voltage adaptor in Photovoltaic mode.

### Filtering (Measurement Quality)

The filtering parameter is to be set depending on the installation type. This parameter is used to smooth out values of insulation measures that always depend on equipment operating on the system. Criteria are:

- Number of loads
- Type of loads
- Size of the system (effects C)
- Load switching

The Vigilohm IM400 is designed to provide accurate insulation resistance and capacitance measurement on highly disturbed systems with power electronic devices. A filtering function is embedded to improve the measurement stability to avoid display fluctuation, undesired transient insulation, and preventive insulation alarm. The response time associated with this filtering function does not affect the IT power system.

Three settings are available for the **Filtering** parameter.

The following table is applicable for IM400/IM400L/IM400C.

Parameter value	Example of use	Measurement refresh time	Response time required to detect an insulation fault (for C = 1 µF)
<b>Short</b>	Recommended in maintenance mode. Diagnose fast variation of the insulation resistance and leakage capacitance. Mostly used in the following cases: <ul style="list-style-type: none"> <li>• Detecting short time transient insulation faults.</li> <li>• When manually locating insulation faults by opening circuit breakers.</li> </ul>	0.8 s (not available in photovoltaic application)	4 s (not available in photovoltaic application)
<b>Medium</b>	Recommended in operation mode. Dedicated to monitor insulation of typical installations.	8 s	40 s
<b>Long</b>	Recommended in operation mode. Dedicated to monitor insulation of highly disturbed installations and/or installations with high leakage capacitance.	80 s	400 s

The following table is applicable for IM400THR/IM400LTHR.

Parameter value	Example of use	Measurement refresh time	Response time required to detect an insulation fault (for C = 1 µF)
<b>2s</b>	Recommended in maintenance mode. Diagnose fast variation of the insulation resistance. Mostly used in the following cases: <ul style="list-style-type: none"> <li>• Detecting short time transient insulation faults.</li> <li>• When manually locating insulation faults by opening circuit breakers.</li> </ul>	0.4 s	2 s
<b>20s</b>	Recommended in operation mode. Dedicated to monitor insulation of typical installations.	4 s	20 s
<b>200s</b>	Recommended in operation mode. Dedicated to monitor insulation of highly disturbed installations.	40 s	200 s

**NOTE:** Using the Photovoltaic mode and the IM400-1700C voltage adaptor, the **Filtering** parameter can be set to **Medium** or **Long**. Using the Photovoltaic mode and the IM400VA2 voltage adaptor, the **Filtering** parameter can be set only to **Long**.

### Locating Insulation Faults

The Vigilohm IM400 can be used with XD301, XD312, or XD308C automatic insulation fault locator or XRM mobile insulation fault locators to detect where the insulation fault is located. Activate or deactivate this feature through **Locating** parameter.

Two settings are available for the **Locating** parameter.

Parameter value	Description
<b>OFF</b>	The Vigilohm IM400 does not inject a fault locating current.
<b>Alarm/Prev.AI.</b>	The Vigilohm IM400 injects a fault locating current compatible with XD301, XD312, XD308C, and XRM devices. Insulation fault location is not compatible with IM400-1700, IM4000VA2, P1N voltage/ground adaptors.

## Voltage Adaptors

The Vigilohm IM400 can be used with IM400-1700, PHT1000, and IM4000VA2 voltage adaptors to monitor power systems with a rated voltage higher than 480 Vac L-L.

IM400-1700 or IM4000VA2 voltage adaptor can also be used in power systems below 480 Vac/dc to increase the internal impedance of the Vigilohm IM400.

The IM400THR/IM400LTHR can be used with P1N ground adaptor and compatible Schneider Electric voltage transformer to monitor power systems with a rated voltage up to 33 kV.

Five settings are available for the **V. Adapt** parameter.

Parameter value	Description
<b>None</b>	Vigilohm IM400 is directly connected to the monitored power system. The power system should have a rated voltage lower or equal to 480 Vac/dc.
<b>HV1700</b>	Vigilohm IM400 uses IM400-1700 voltage adaptor to connect to the monitored network ( <i>see page 14</i> ). Locating an insulation fault cannot be done using Vigilohm IM400 with IM400-1700. <b>HV1700</b> cannot be set up when the parameter <b>Locating</b> is set to <b>ON</b> .
<b>PHT1000</b>	Vigilohm IM400 uses PHT1000 voltage adaptor to connect to the monitored network ( <i>see page 14</i> ). Locating an insulation fault can be done using Vigilohm IM400 with PHT1000.
<b>IM400VA2</b>	Vigilohm IM400 uses IM4000VA2 voltage adaptor to connect to the monitored network ( <i>see page 14</i> ). Locating an insulation fault cannot be done using Vigilohm IM400 with IM4000VA2. <b>IM400VA2</b> cannot be set up when the parameter <b>Locating</b> is set to <b>ON</b> .
<b>P1N</b>	Vigilohm IM400 uses P1N ground adaptor to connect to the monitored network ( <i>see page 14</i> ).

**NOTE:** For IM400THR/IM400LTHR, the **V.Adapt** parameter values are **None** and **P1N** only.

## System Frequency

**NOTE:** This parameter is applicable for IM400/IM400L/IM400C.

This is the rated frequency of the monitored power system.

Four settings are available for the **Frequency** parameter:

- DC
- 50 Hz
- 60 Hz
- 400 Hz

## Injection

This is the level of measurement voltage and measurement current that are injected between the monitored power system and ground.

Four settings are available for the **Injection** parameter.

The following table is applicable for IM400/IM400L/IM400C.

Parameter value	Example of use	Measurement voltage value	Measurement current value
<b>Min</b>	Sensitive control circuits	< 15 V <sub>peak</sub>	< 375 μA <sub>peak</sub>
<b>Low</b>	Not sensitive control circuits or power circuits with low values of leakage capacitance	< 33 V <sub>peak</sub>	< 825 μA <sub>peak</sub>
<b>Std</b>	Power circuit applications with high values of leakage capacitance	< 120 V <sub>peak</sub>	< 3 mA <sub>peak</sub>
<b>Max</b> (setting applicable only if used with IM400-1700C or M400VA2 voltage adaptor)	Photovoltaic application	< 120 V <sub>peak</sub>	< 300 μA <sub>peak</sub>

The following table is applicable for IM400THR/IM400LTHR.

Parameter value	Measurement current value
20V	< 469 $\mu$ Adc
40V	< 940 $\mu$ Adc
60V	< 1.56 mAdc
80V	< 2.48 mAdc

### High Resistance Grounding (HRG)

The Vigilohm IM400 can be used to monitor power systems with a grounding resistance inserted between the neutral and the earth.

If the value of this neutral grounding resistance is entered through the **HRG** (High-Resistance Grounding) parameter, the Vigilohm IM400 compensates the measured insulation resistance. It does it with the value of the neutral grounding resistance, offsetting it to report the actual insulation resistance. In this case, the actual insulation resistance (derived after compensating the neutral grounding resistance) is compared against the insulation alarm threshold and the preventive alarm threshold to trigger the insulation and preventive insulation alarm relays.

HRG compensation is applicable only if the neutral is connected to ground through a resistance. HRG is not compatible with RLC (non-linear) grounding circuits.

Two settings are available for the **HRG** parameter.

Parameter value	Description
OFF	The Vigilohm IM400 does not compensate the reported insulation resistance with the value of the neutral grounding resistance.
0.1...500 k $\Omega$	The Vigilohm IM400 compensates the measured insulation resistance with the value of the neutral grounding resistance.

### Primary DC Resistance (Pri. DC Resis))

**NOTE:** This parameter is applicable for IM400THR/IM400LTHR and when **V.Adapt** parameter value is set to **P1N**.

This is the value of resistance of the compatible Schneider Electric voltage transformer primary winding. You can select any value from **0** to **50** k $\Omega$ .

If you have connected more than 1 transformer, select the value of resistance of single transformer. IM400THR/IM400LTHR automatically calculates the total resistance depending on the value of the number of transformer parameter.

### Number of Transformer (No. of Transfo))

**NOTE:** This parameter is applicable for IM400THR/IM400LTHR and when **V.Adapt** parameter value is set to **P1N**.

This is the value of number of transformer connected.

Three settings are available for the **No. of Transfo** parameter:

- 0
- 1
- 3


### Example of set Primary DC Resistance and Number of Transformer

If	Then
You have connected 3 transformers and DC primary resistance of each transformer is 15 k $\Omega$ .	Select <b>15 k<math>\Omega</math></b> value for <b>Pri.DC Resis</b> parameter. Set <b>3</b> value for <b>No. of Transfo</b> parameter.
You have connected 1 transformer and DC primary resistance of transformer is 15 k $\Omega$ .	Select <b>15 k<math>\Omega</math></b> value for <b>Pri.DC Resis</b> parameter. Set <b>1</b> value for <b>No. of Transfo</b> parameter.

## Monitoring the System Insulation

### Functional Description

The Vigilohm monitors the IT system insulation resistance (kΩ) in accordance with the following timing diagram:



(1) In this example, Insulation Alarm Relay parameter (Menu → Settings → I/O Config.. → Ins. Al. Relay) is setup in Failsafe mode.

- 0 An insulation decrease is detected on the system. The insulation resistance drops below the preventive insulation alarm threshold. The preventive insulation alarm relay switches and the preventive insulation alarm indicator light lights up.
- 1 An insulation fault is detected on the system.
- 2 Once T (insulation alarm delay) has elapsed, Vigilohm IM400 switches to the insulation alarm state. The insulation alarm relay switches and the insulation alarm indicator light lights up.
- 3 Press the button to acknowledge the insulation alarm. Both the insulation alarm relay and the preventive insulation alarm relay toggle back to their initial state. Depending on the setup of the I/Os, the preventive insulation alarm relay and the insulation alarm relay may or may not toggle back to their initial states. The timing diagram above represents the case when the I/Os are set up to acknowledge the relays (see page 43).
- 4 The insulation fault has been corrected or disappeared. Vigilohm IM400 reverts to normal status.

When the Vigilohm in the insulation alarm state is not acknowledged by the user, and the insulation rises again above the insulation alarm threshold, then the insulation fault is recorded as transient.

### Status Information

The display and the five indicator lights on Vigilohm IM400 indicate the current status of the product.

Indicator lights					Description
Product status	Modbus communication status	Insulation status	Preventive insulation alarm	Insulation alarm	
OFF	OFF	OFF	OFF	OFF	Vigilohm IM400 de-energized.
OFF	–	ON	OFF	OFF	Vigilohm IM400 energized. No insulation fault detected.
OFF	–	OFF	ON	OFF	Vigilohm IM400 energized. Preventive insulation alarm detected.
OFF	–	OFF	OFF	ON	Vigilohm IM400 energized. Insulation fault detected.
OFF	–	ON	OFF	Flashing	Vigilohm IM400 energized. No insulation fault detected but transient insulation fault has been detected.
OFF	–	OFF	ON	Flashing	Vigilohm IM400 energized. Preventive insulation alarm detected. Transient insulation fault has been detected.
OFF	–	Flashing	OFF	OFF	Vigilohm IM400 energized. Injection de-activated by using injection inhibition input.
OFF	Flashing	–	–	–	Vigilohm IM400 energized. Modbus communication active.
ON	OFF	OFF	OFF	OFF	Vigilohm IM400 energized but inoperative. The IM400 product and its installation should be checked by a maintenance operator.

### Insulation Alarm and Preventive Insulation Alarm Thresholds

Two methods are available for changing the Vigilohm IM400 insulation alarm and preventive insulation alarm thresholds:

- Manually set the corresponding parameter by selecting **Menu → Settings → Ins. Alarm**, or
- Use Modbus communication (*see page 74*).

The available settings for the insulation alarm and preventive insulation alarm thresholds are as follows:

Threshold	Setting range	Factory value
Insulation alarm	0.04...500 kΩ	1 kΩ
Preventive insulation alarm	<ul style="list-style-type: none"> <li>• 1 kΩ...1 MΩ</li> <li>• OFF</li> </ul>	OFF

Insulation alarm and preventive insulation alarm thresholds are saved in an internal non-volatile memory. They remain unchanged after a power cut.

The preventive insulation alarm threshold must always be set higher than the insulation alarm threshold.

An insulation alarm is cleared when the insulation level reaches 20% above the threshold.

### Hysteresis on Alarm and Preventive Insulation Alarm Thresholds


When the measured insulation value is close to the setup threshold, fluctuations of measures can trigger erroneous preventive insulation alarms because the measure fluctuates around the threshold.

To limit the instability, a hysteresis principle is applied:


- When the measured insulation value decreases and drops below the setup threshold, the insulation alarm or preventive insulation alarm is triggered or the countdown begins if an insulation alarm delay has been set-up.
- When the measured insulation value increases and reaches a value above 1.2 time the threshold of the setting (that is, setup threshold value +20%), the alarm or the preventive insulation alarm is deactivated.

The following diagrams show the behaviors:

- Insulation monitoring device without hysteresis:



- Vigilohm with 20% hysteresis:



### Insulation Alarm and Preventive Insulation Alarm Time Delays

Insulation alarm and preventive insulation alarm delays are time filters. They are used to filter transient insulation faults. They can also be used in harsh electrical systems to avoid false Insulation alarms and preventive insulation alarms. Especially in photovoltaic applications, it is usual to see filtering time of several minutes to filter false alarms at startup. The Vigilohm IM400 does not report insulation faults that do not remain for a duration longer than the delays set up.

To access the time delay parameter, select **Menu → Settings → Ins. Alarm**.

Setting	Setting range	Factory value
<b>Ins. Al. Delay</b> (insulation alarm time delay)	0 s... 120 minutes	0 s
<b>Prev. Al. Del.</b> (preventive insulation alarm time delay)	0 s... 120 minutes	0 s

**NOTE:** The preventive insulation alarm time delay setup is not displayed when the preventive insulation alarm threshold value is set to **OFF**.

### Detecting Disconnection of Injection Wiring Terminal

This function is based on the detection of a high insulation resistance in the system, and allows the following disconnections to be detected:

- Injection wire.
- Ground wire.
- Between Vigilohm IM400 and IM400-1700 voltage adaptor.
- Between Vigilohm IM400 and PHT1000 voltage adaptor.
- Between Vigilohm IM400 and IM400VA2 voltage adaptor.

To access the parameter, select **Menu → Settings → Ins. Alarm**.

Setting	Setting range	Factory value
<b>Disconnect. Inj.</b> (disconnected injection)	ON / OFF	OFF

On small networks without loads and IT transformer, where the insulation level is high, or during commissioning without loads and without IT transformer, it is recommended to set the parameter to **OFF**. Detection of disconnection between Vigilohm IM400 and IM400-1700 or PHT1000 or IM400VA2 voltage adaptors is always active and does not depend on the value of the **Disconnect. Inj.** parameter. If the injection disconnects, Vigilohm IM400 triggers a product status alarm, described in Disconnected Injection Detection (*see page 64*). The product status LED becomes red.

### Insulation Alarm Relay

Depending on the status of the insulation, the insulation alarm relay is activated or deactivated according to the mode selected:

- Failsafe (factory setting)
- Standard

To access the insulation alarm relay parameter, select **Menu → Settings → I/O Config.**

Setting	Setting range	Factory value
<b>Ins. Al. Relay</b> (insulation alarm relay)	FS / STD	FS

When the insulation alarm relay is configured in failsafe (**FS**) mode:

- The insulation alarm relay is activated (energized) in the following case:
  - No insulation fault is being detected.
  - Injection is inhibited (selecting **Menu → Settings → I/O Config. → Ack Inhibit**, set to **ON**).
- The insulation alarm relay is deactivated (de-energized) in the following cases:
  - Preventive insulation fault is being detected.
  - Insulation fault is being detected.
  - A special insulation status is detected (*see page 64*).
  - The product is inoperative (detected by self-test).
  - The auxiliary power supply is lost.
  - Corrected insulation fault signal: the insulation fault relay toggles for 3 seconds when an insulation fault has been detected, acknowledged, and later corrected in the power system (*see page 44*).
  - When the user triggers a self-test with relays (selecting **Menu → Settings → I/O Config. → Test. w. Relays**, set to **ON**), the insulation alarm relay toggles for 3 seconds (*see page 56*).
  - Injection is inhibited (selecting **Menu → Settings → I/O Config. → Ack Inhibit**, set to **ON**), the preventive insulation fault is being detected (*see page 56*).

When the insulation alarm relay is configured in standard (**Std.**) mode:

- The insulation alarm relay is activated (energized) in the following cases:
  - A preventive insulation fault is being detected.
  - Insulation fault is being detected.
  - A special insulation status is detected (*see page 64*).
  - The product is inoperative (detected by self-test).
  - Corrected insulation fault signal: the insulation fault relay toggles for 3 seconds when an insulation fault has been detected, acknowledged, and later corrected in the power system (*see page 44*).
  - When the user triggers a self-test with relays (selecting **Menu → Settings → I/O Config. → Test. w. Relays**, set to **ON**), the insulation alarm relay toggles for 3 seconds (*see page 56*).
  - Injection is inhibited (selecting **Menu → Settings → I/O Config. → Ack Inhibit**, set to **ON**).
- The insulation alarm relay is deactivated (de-energized) in the following cases:
  - No insulation fault is being detected.
  - Insulation fault is being detected and acknowledged. Acknowledgement of the insulation alarm relay is activated (selecting **Menu → Settings → I/O Config. → Ack. Al. Relay**, set to **ON**).
  - The auxiliary power supply is lost.

### Preventive Insulation Alarm Relay

To access the preventive insulation alarm relay parameter, select **Menu → Settings → I/O Config.**

Setting	Setting range	Factory value
<b>Prev. Al. Relay</b> (preventive insulation alarm relay)	Std. / FS / Mirror	FS

		ENERGIZED PRODUCT					DE-ENERGIZED PRODUCT
	I/O Config.	Relay State	Normal Operation / No Insulation Fault	Preventive Insulation Alarm	Insulation Alarm	Inoperative / Special Status	
Insulation Alarm Relay	Failsafe	ON					
		OFF					
	Standard	ON					
		OFF					
Preventive Insulation Alarm Relay (Prev. Ins. Alarm Threshold not OFF)	Failsafe	ON					
		OFF					
	Standard	ON					
		OFF					
Preventive Insulation Alarm Relay in Mirror mode	Insulation alarm relay Failsafe	ON					
		OFF					
	Insulation alarm relay Standard	ON					
		OFF					

States in which insulation alarm relay is mirrored

States in which both relays are identical

When the preventive insulation alarm relay is configured in failsafe (FS) mode:

- The preventive insulation alarm relay is activated (energized) in the following case:
  - No insulation fault is being detected.
- The preventive insulation alarm relay is deactivated (de-energized) in the following cases:
  - Preventive insulation fault is being detected.
  - Insulation fault is being detected.
  - A special insulation status is detected (*see page 64*).
  - The product is inoperative (detected by self-test).
  - The auxiliary power supply is lost.
  - When the user triggers a self-test with relays (selecting **Menu** → **Settings** → **I/O Config.** → **Test. w. Relays**, set to **ON**), the preventive insulation alarm relay toggles for 3 seconds (*see page 56*).

When the preventive insulation alarm relay is configured in standard (Std.) mode:

- The preventive insulation alarm relay is activated (energized) in the following cases:
  - The preventive insulation fault is being detected.
  - Insulation fault is being detected.
  - A special insulation status is detected (*see page 64*).
  - The product is inoperative (detected by self-test).
  - When the user triggers a self-test with relays (selecting **Menu** → **Settings** → **I/O Config.** → **Test. w. Relays**, set to **ON**), the preventive insulation alarm relay toggles for 3 seconds (*see page 56*).
- The preventive insulation alarm relay is deactivated (de-energized) in the following cases:
  - No insulation fault is being detected.
  - The auxiliary power supply is lost.

When the preventive insulation alarm relay is set up in mirror mode (by selecting **Menu** → **Settings** → **I/O Config** → **Prev. Al. Rel** → **Mirror**):

- The preventive insulation alarm relay mirrors (symmetrically matches) the insulation alarm relay as long as the Vigilohm IM400 is operating correctly (*see page 27*).
- The preventive insulation alarm relay stops mirroring the insulation alarms when the Vigilohm IM400 is de-energized or inoperative. This feature can be used to detect an inoperative product.


### Examples of Application of Preventive Alarm Relay Mirroring Modes

Some applications require that when an IMD device becomes inoperative, the system automatically switches to another IMD device by managing exclusions using the injection inhibition input (*see page 50*).

Using the preventive insulation alarm relay configured in mirror mode, the relays can be wired in series creating a logical AND function. It is recommended to configure the insulation alarm relay in failsafe mode and wire both relays in (NC/C).

In this case, the logical function returns true only when the device is inoperative or de-energized, or when a special status is active.

The following wiring diagram is an example of the Vigilohm IM400 wired in Standard mode:




- A Preventive insulation alarm (configured in standard mode)
- B Insulation alarm (configured in standard mode)

Standard Mode Configuration

Mode	Input	State				
		No fault	Preventive alarm	Alarm	Inoperative product	No power
Standard	PLC 1	1	1	1	0	0
Standard	PLC 2	1	1	0	0	1

The following wiring diagram shows how to wire the Vigilohm IM400 in FS mode:



- A Preventive insulation alarm (configured in FS mode)
- B Insulation alarm (configured in FS mode)

Failsafe (FS) Mode Configuration

Mode	Input	State				
		No fault	Preventive alarm	Alarm	Inoperative product	No power
FS	PLC 1	0	0	0	1	1
FS	PLC 2	0	0	1	1	1

**ALARM=(RelayState:ON) || ((StatusInput:CLOSED) & (RelayState:OFF))**

- An insulation alarm is detected when both PLC inputs are at a logic 1.
- A product failure is detected when PLC input 1 is a logic 0.

**Insulation Alarm Relay Acknowledgement**

When the relays are connected to loads (for example, horns or lamps), it is recommended to turn off these external signaling devices before the insulation level rises back to a level above the setup thresholds. This can be done by clicking the acknowledge button while in insulation alarm state.


In certain system configurations, it is required to prevent this type of user acknowledgement and only retrigger the relays when the insulation level rises above the setup thresholds. This is done by changing the corresponding parameter.

To acknowledge the insulation alarm relay parameter, select **Menu → Settings → I/O Config.**

Setting	Setting range	Factory value
Ack. Al. Relay (acknowledgement insulation alarm relay)	ON / OFF	ON


When the Vigilohm IM400 detects an insulation fault, both the preventive insulation alarm relay and the insulation alarm relay are triggered, depending on the setup.

- Acknowledgement of relays set to **ON**



**3** Insulation fault alarm acknowledgement switches back the relays to their initial position.

- Acknowledgement of relays set to **OFF**



3 Insulation fault alarm acknowledgement does not switch back the relays to their initial position.

### Corrected Insulation Fault Signal

In order to facilitate insulation fault detection, the insulation alarm relay can be reactivated for 3 seconds when the insulation level rises above the setup threshold.

This makes it easier to locate the insulation fault when using the method that involves opening each of the circuit breakers in turn. Given that the circuit breakers may be located at some distance from the Vigilohm IM400, the external signal allows you to identify and locate the insulation fault when working remotely. This option can be activated by changing the corresponding parameter.


To access the option, select **Menu** → **Settings** → **I/O Config**.

Setting	Setting range	Factory value
Corr. Flt Signal (corrected fault signal)	ON / OFF	OFF

**NOTE:** Corrected insulation fault signal is applicable only if the parameter **Ack. Al. Relay** (acknowledgement insulation alarm relay) is set to **ON**.


In system configurations where the insulation alarm relay is connected to an external signaling device (for example, horns or lamps), the relays are triggered back to their normal position, depending on their setup, when the insulation alarm is acknowledged.

- Corrected insulation fault signal set to ON



④ After correcting the insulation fault in the power system, the insulation fault alarm relay toggles for 3 s.

- Corrected insulation fault signal set to OFF



④ After correcting the insulation fault in the power system, the insulation fault alarm relay does not toggle for 3 s.

## Operation on Systems with a Voltage Greater Than 480 Vac/dc

### Operation

A voltage adaptor is required when the device is connected to one of the following systems:

- system voltage greater than 830 Vac Ph-Ph and the Vigilohm IM400 is connected to an accessible neutral.
- system voltage greater than 480 Vac and the Vigilohm IM400 is connected to a phase (non-accessible neutral).
- system voltage greater than 480 Vdc.

See the specifications for information about the maximum voltage (*see page 99*).

For Vigilohm IM400 operation without insulation fault location (XD301, XD312, XD308C, or XRM not used), the IM400-1700 or IM400VA2 voltage adaptor can be used.

For Vigilohm IM400 operation with insulation fault location (XD301, XD312, XD308C, or XRM used), the PHT1000 voltage adaptor must be used.

**NOTE:** The **V. Adapt** parameter cannot be set up as **HV1700** or **VA2** if the parameter **Locating** is set to **ON**.

### V. Adapt Parameter

Configure the **V. Adapt** parameter as follows:

- **HV1700** for the IM400-1700 voltage adaptor
- **PHT1000** for the PHT1000 voltage adaptor
- **VA2** for the IM400VA2 voltage adaptor

The factory value is **None** (operation without voltage adaptor).

## Operation on Systems with Medium Voltage

### Operation

A voltage/ground adaptor and a compatible Schneider Electric voltage transformer are required when the device is connected to one of the following systems:

- system voltage up to 33k Vac Ph-Ph and the Vigilohm IM400THR/IM400LTHR is connected to an accessible neutral.
- system voltage up to 33k Vac and the Vigilohm IM400THR/IM400LTHR is connected to a phase (non-accessible neutral).

## Insulation Fault Location

### Locating Insulation Faults Automatically

Vigilohm IM400 is compatible with the XD\*\*\* range of insulation fault locators from the Vigilohm offer:

- XD301: one-channel insulation fault locator with indicator light and one output relay (commercial references 50506, 50507, and 50508)
- XD312: twelve-channel insulation fault locator with one indicator light per channel and one output relay (commercial references 50535, 50536, and 50537)
- XD308C: eight-channel insulation fault locator with communication (requires an XLI300 communication interface) (commercial references 50723, 50724, and 50725)

The **Locating** parameter can be configured in three modes:

- Alarm: The IMD injects the locating current as soon as an Insulation Alarm is detected.
- PreAlarm: The IMD injects the locating current as soon as an Insulation Alarm OR Insulation PreAlarm is detected.
- OFF: The IMD disables fault locating function and will not inject the locating current. This mode is used for photovoltaic applications.

### Locating Insulation Faults Manually

From the Vigilohm offer, the mobile insulation fault locating devices must be used for:

- Insulation fault location on a feeder not equipped with an automatic insulation fault locator, or
- Facilitating the location of an insulation fault on a feeder.

The **Locating** parameter must be configured to **Alarm** or **PreAlarm**.

The signal injected by IM400 is compatible with the XP15, XP50, XP100, and XRM devices. Proceed as follows:

1. Connect the XP\*\* to XRM.
2. Use this to an inject wire close to IM400.
3. Calibrate the XRM to 18.
4. Use the XP\*\* and XRM on all the feeders to locate an insulation fault.

If the XRM reports 18, it indicates an insulation fault in the feeders or the downstream to the clamp.

Refer to the *Vigilohm Catalog* for information about the mobile insulation fault locating devices:

- XRM locating signal receiver (commercial reference 50278)
- Open-clamp current probes (commercial references XP15 494, XP50 498, XP100 499)

**NOTE:** In manual fault location mode with IM400, XGR injector is not required.

## Injection Inhibition Input and Exclusion Management

### Exclusion

The IMD injects several patented combinations of low frequency voltage into the system. In a system with several incoming feeders, depending on the circuit breaker position, there must be no more than one IMD injecting into the system.

The inhibition of injection is managed by the state of inhibition input of Vigilohm IM400, which can, for example, be connected to the auxiliary contacts of the circuit breakers.

The injection inhibition input can be configured to use an NO or an NC contact as shown below:

Contact type	Injection activated when the contact is...	Injection deactivated when the contact is...
NO (factory value)	Open	Closed
NC	Closed	Open
OFF	Ignored	Ignored

The Inhibit Input parameter can also be set to OFF. In this mode, the electrical input state is ignored and the exclusion management can still be done over Modbus communication (Table of Modbus Functions, [\(see page 73\)](#)). This is especially useful in functional safety standards compliant environments (Functional Safety Standards Compliance, [\(see page 91\)](#)).


Configuring the injection inhibition input functions allows the triggering of the insulation alarm relay when the injection is disabled. This feature is critical in an UL-FS type environment to obtain a feedback (acknowledgment) on the injection status.

To activate this function the following parameter must be set to **ON** in **Menu → Settings → I/O Config**:


Setting	Setting range	Factory value
<b>Ack Inhibit</b> (acknowledgement of the inhibition signal)	ON /OFF	OFF

### Example of Exclusion with Two Incoming Feeders

Using circuit breakers with normally open (NO) auxiliary contacts:




Using circuit breakers with normally closed (NC) auxiliary contacts:




If	Then
<ul style="list-style-type: none"> <li>● If D1 is closed and</li> <li>● D2 is open</li> </ul>	The two Vigilohm IM400 devices are active: <ul style="list-style-type: none"> <li>● Vigilohm IM400 no.1 monitors the system insulation.</li> <li>● Vigilohm IM400 no.2 only monitors the insulation of the transformer 2 connection as far as D2.</li> </ul>
<ul style="list-style-type: none"> <li>● If D1 is open and</li> <li>● D2 is closed</li> </ul>	The two Vigilohm IM400 devices are active: <ul style="list-style-type: none"> <li>● Vigilohm IM400 no.1 monitors the insulation of the transformer 1 connection as far as D1.</li> <li>● Vigilohm IM400 no.2 monitors the system insulation.</li> </ul>
<ul style="list-style-type: none"> <li>● If D1 is closed and</li> <li>● D2 is closed</li> </ul>	<ul style="list-style-type: none"> <li>● Vigilohm IM400 no.1 is active and monitors the system insulation.</li> <li>● Vigilohm IM400 no.2 must be inhibited.</li> </ul>

### Example of Exclusion with Two Incoming Feeders and One Coupling

Using circuit breakers with normally open (NO) auxiliary contacts:



Using circuit breakers with normally closed (NC) auxiliary contacts:




If	Then
If the coupling (C) is closed	The same applies as in the exclusion example above involving two incoming feeders (see page 50).
<ul style="list-style-type: none"> <li>• If the coupling is open and</li> <li>• D1 is closed</li> <li>• D2 is closed</li> </ul>	The two Vigilohm IM400 devices are active: <ul style="list-style-type: none"> <li>• Vigilohm IM400 no.1 monitors the insulation of system 1.</li> <li>• Vigilohm IM400 no.2 monitors the insulation of system 2.</li> </ul>

Vigilohm IM400 no.2 must be inhibited when the following three conditions are met:


- D1 is closed.
- D2 is closed.
- C is closed.

### Example of Exclusion with Three Incoming Feeders

Using circuit breakers with normally open (NO) auxiliary contacts:



Using circuit breakers with normally closed (NC) auxiliary contacts:



The IMD priority is as follows:

- IM400 no.1 is the IMD with the highest priority 1: it always injects into the systems no matter if D1 is closed or open.
- IM400 no.2 is the IMD with priority 2: it always injects into the system except when there is a closed path between it and one IMD with a higher priority, that is, in this case IM400 no.1. Therefore, IM400 no.2 is inhibited when D2 and D1 are closed:  
IM400 no.2 injection inhibition = D1 AND D2.  
This logic is implemented by wiring the injection inhibition of IM400 no.2 to the 2 auxiliary contacts of D1 and D2.
- IM400 no.3 is the IMD with priority 3: it always injects into the system except when there is a closed path between it and one IMD with a higher priority, that is, in this case IM400 no.1 or IM400 no.2. Therefore, IM400 no.3 is inhibited when D3 and D2 are closed, or D3 and D1 are closed:  
IM400 no.3 injection inhibition = (D3 AND D1) OR (D3 AND D2) = D3 AND (D1 OR D2) This logic is implemented by wiring the injection inhibition of IM400 no.3 to the auxiliary contacts of D1 and D2 and D3.

### Example of Exclusion with Multiple Incoming Feeders and Couplings


For complex configurations where, there are multiple incoming feeders and couplings, it is required to use a basic Programmable Logic Controller (PLC) to manage the exclusion of IMD.

The PLC can have the following characteristics:

- Number of digital inputs: is the number of circuit breakers for incoming feeder and for coupling. These inputs can be self-powered by the PLC or powered by an external power supply.
- Number of digital outputs: is the number of IMDs -1. These digital outputs can be electromechanical or solid-state outputs.
- Processing cycle is equal to 0.1 s or less.

Using a basic PLC to manage IMD exclusion allows to:

- Monitor continuously each part of IT power system.
- Have a short response time to detect insulation faults.
- Be compatible with complex power systems with high number of incoming feeders and couplings.



There are two methods to determine the logic driving the injection inhibition input of each IMD:

**Method 1:** Give a priority to each IMD using indexes of incoming feeders. In this example:

- Priority of IM400 no.1 is 1 (highest priority),
  - Priority of IM400 no.2 is 2,
  - Priority of IM400 no.3 is 3,
  - Priority of IM400 no.4 is 4 (lowest priority).
- IM400 no.1 with the highest priority is always injecting, its injection inhibition input is left unwired.
  - IM400 no.2 with the priority 2 always injection into the system except when there is a closed path between itself and one IMD with a higher priority, that is, IM400 no.1 in this case. The closed path occurs when D2, C1 and D1 are closed.

Therefore:

Injection inhibition of IM400 no2 =  
 $D2 \text{ AND } C1 \text{ AND } D1$

The representation in Ladder PLC programming language is as follows:



- IM400 no.3 with the priority 3 always injection into the system except when there is a closed path between itself and one IMD with a higher priority, that is, IM400 no.2 and IM400 no.1 in this case.

The closed path occurs when:

- (D3, C2, and D2) are closed, or
- (D3, C2, C1, and D1) are closed.

Therefore:

- Injection inhibition of IM400 no.3 =  
 $(D3 \text{ AND } C2 \text{ AND } D2) \text{ OR } (D3 \text{ AND } C2 \text{ AND } C1 \text{ AND } D1)$
- Injection inhibition of IM400 no.3 =  
 $(D3 \text{ AND } C2) \text{ AND } (D2 \text{ OR } (C1 \text{ AND } D1))$

The representation in Ladder PLC programming language is as follows:



- IM400 no.4 with the priority 4 always injection into the system except when there is a closed path between itself and one IMD with a higher priority, that is, IM400 no.3, IM400 no.2, and IM400 no.1 in this case.


The closed path occurs when:

- (D4, C3, and D3) are closed, or
- (D4, C3, C2, and D2) are closed, or
- (D4, C3, C2, C1, and D1) are closed.

Therefore:

- Injection inhibition of IM400 no.4 =  
(D4 AND C3 AND D3) OR (D4 AND C3 AND C2 AND D2) OR (D4 AND C3 AND C2 AND C1 AND D1)
- Injection inhibition of IM400 no.3 =  
(D4 AND C3) AND (D3 OR (C2 AND D2) OR (C2 AND C1 AND D1))

The representation in Ladder PLC programming language is as follows:



**Method 2:** Use a truth table.

Possible configurations							1 = Injection inhibition			
D1	D2	D3	D4	C1	C2	C3	IM400 no.1	IM400 no.2	IM400 no.3	IM400 no.4
0	0	0	0	0	0	0	0 <sup>(1)</sup>	0 <sup>(1)</sup>	0 <sup>(1)</sup>	0 <sup>(1)</sup>
0	0	0	0	0	0	1	0 <sup>(1)</sup>	0 <sup>(1)</sup>	0 <sup>(1)</sup>	0 <sup>(1)</sup>
...										
0	1	1	1	1	0	1	0 <sup>(1)</sup>	0 <sup>(2)</sup>	0 <sup>(2)</sup>	1 <sup>(3)</sup>
...										
1	1	1	1	0	0	0	0 <sup>(2)</sup>	0 <sup>(2)</sup>	0 <sup>(2)</sup>	0 <sup>(2)</sup>
...										
1	1	1	1	1	1	1	0 <sup>(2)</sup>	1 <sup>(3)</sup>	1 <sup>(3)</sup>	1 <sup>(3)</sup>

(1) Vigilohm IM400 monitors the transformer.  
 (2) Vigilohm IM400 injects a signal into the system.  
 (3) Vigilohm IM400 is excluded from the system (injection inhibited).

### Injection Inhibition Screen

When the injection inhibition function of Vigilohm IM400 is activated (that is, **Inhibit. Input** set to **N.O.**), the screen below appears and replaces any system status screen that may be showing already (insulation measurement, insulation alarm, or preventive insulation alarm):



You can perform the following actions on this screen:

- Press the **MENU** button to access the main menu.
- Press the arrow contextual menu buttons to view the setting screen.
- Press the contextual menu button to launch the self-test.

**NOTE:** When activating injection again (that is, **Inhibit. Input** set to **N.C.**), a self-test is launched automatically before returning to the default insulation monitoring screen.

## Self-Test

### Description

The Vigilohm has a self-test function for testing:

- The product: indicator lights, internal electronics
- The measurement system, and the insulation alarm and preventive insulation alarm relays

### Running the Self-Test

The test can be run/runs:

- Manually at any time by pressing the  contextual menu button on one of the system insulation monitoring screens
- Automatically:
  - Whenever the device starts up (power-up or reset)
  - Every five hours (except when the device is in the insulation alarm status, regardless of whether the insulation alarm is active or has been acknowledged)
  - Whenever leaving the inhibited injection state (**Inhibit. Input**) when injection is activated again.

### Sequence of Indicator Lights

During the verification sequence, the indicator lights light up in the following order:

- Insulation status yellow
- Preventive insulation alarm white
- Insulation status green
- Modbus communication yellow
- Product status red

### Test with Relays


Use this setting to select whether to include a three-second toggle of the preventive insulation alarm relay and insulation alarm relay during a manually launched self-test.

To access the test with relay parameter, select **Menu** → **Settings** → **I/O Config**.

Setting	Setting range	Factory value
<b>Test w. Relays</b> (test with relays)	ON / OFF	ON

### Self-Test OK

If the self-test is successful, the following screen appears for three seconds:



After that, a measurement phase shown by a progress bar at the bottom of the screen appears, and then one of the status screens automatically appears (system insulation resistance measurement or insulation fault alarm).

### Self-Test Not OK

If the self-test is not successful, the product automatically restarts. If the problem persists:

- The red status indicator LED switches on.
- The insulation alarm relay is triggered
- A product **inoperative message** is displayed.

If this happens, briefly disconnect the auxiliary power supply of the Vigilohm. If the problem persists, contact the Schneider Electric Customer Care Center.

---

# Chapter 4

## Human Machine Interface

---

### Presentation

The Vigilohm features a sophisticated and intuitive human machine interface (HMI) with signaling indicator lights, a graphic display, and contextual menu buttons for accessing the information required to operate the Vigilohm and make parameter settings.


### What Is in This Chapter?

This chapter contains the following topics:


Topic	Page
Vigilohm IM400 Menu Structure	58
Navigating the Interface	60
Status Screens	62
Special Status Screens	64
Modifying Parameters	66
Clock	68
Insulation Fault Log	69
Trend Screens	70

## Vigilohm IM400 Menu Structure

### Vigilohm IM400/IM400C/IM400L Menu Structure




Vigilohm IM400THR/IM400LTHR Menu Structure



## Navigating the Interface

### Presentation


The diagram below illustrates the various elements for operating the Vigilohm.



- 1 Screen identification area containing a menu icon, and the name of the menu or parameter
- 2 Information area for displaying screen-specific details (measurement, insulation alarm, setting)
- 3 Navigation buttons

### Navigation Buttons

The navigation buttons enable quick and intuitive navigation:



Legend	Button	Icon	Description
1	<b>MENU</b>	–	Displays the level 1 main menu
2	<b>ESC</b>	–	Takes you back to the previous level
3	Contextual menu button 3		For scrolling up the display or moving to the previous item in a list
			For accessing the date and time setting If the clock icon flashes, it means that the Date/Time parameter needs to be set.
			For increasing a numerical value
4	Contextual menu button 2		For scrolling down the display or moving to the next item in a list
			For moving one digit to the left within a numerical value. If the digit on the far left is already selected, pressing the button loops you back to the digit on the right.
			For moving 1 digit to the right within a numerical value
5	Contextual menu button 1		For validating the selected item
			For executing the manual test
			For accessing a menu or submenu, or for editing a parameter
			For acknowledging insulation alarms

## Information Icons

This table describes the icons provided for information in the information area of the LCD display. Among other things, they indicate which menu is selected or the insulation alarm status.

Icon	Description
	Main menu
	<ul style="list-style-type: none"> <li>Identifies the system resistance when there is no insulation fault</li> <li>Measurement parameter menu</li> </ul>
	Insulation fault log menu
	Trend menu
	Setting parameter menu
	Interface language selection menu
	Product identification
	Indicates an insulation fault alarm or preventive insulation alarm


## Status Screens

### Presentation

The default screen shows the insulation resistance value of the system. This screen is automatically replaced by an alert screen when an insulation alarm occurs.

The screen backlight flashes to indicate an insulation alarm.

Each insulation measurement screen displays a status bar at the bottom that provides additional information. In general, it shows the date and time of the insulation fault.



- 1 Insulation value
- 2 Progress bar for the refresh time
- 3 Bargraph indicating the insulation level on a logarithmic scale. The  symbol indicates the insulation alarm threshold value.
- 4 Status bar displaying additional information related to the current insulation alarm state. Different types of status bar are available (see note below).
- 5 Contextual buttons for navigating the insulation screens or for launching a manual self-test.

**NOTE:** The different types of status bar are:


- Current date and time: displayed when product is in normal operation (no insulation fault detected)
- Insulation alarm active time delay: an insulation fault has been measured and the insulation alarm time delay is active. This bar shows a progress bar for the time delay.
- Insulation alarm pickup date and time
- Insulation alarm dropout date and time
- Insulation alarm relay acknowledgment

The bars can also indicate:

- a cyclic self-test is running in the background
- a first measurement is in progress (at startup or after reactivating the injection function)


### System Insulation Resistance Measurement (R)

The Vigilohm displays the insulation resistance measurement for the system by default. The status bar shows the current time of the IMD.



### Insulation Alarm Detected: Insulation Fault Message

The following screen displays when the insulation value drops below the insulation alarm threshold:




There are 2 possible scenarios:

- Acknowledge the insulation alarm by pressing the  contextual menu button.
- If you do not acknowledge the insulation alarm and the system insulation returns to a value above the insulation alarm threshold, this results in a transient insulation fault.


### Insulation Alarm Acknowledged

The following screen appears once the insulation alarm is acknowledged. The status bar shows the time when the insulation fault is acknowledged.




### Preventive Insulation Alarm Activated

The following screen appears when the preventive insulation alarm is activated:



### Transient Insulation Fault Message

The following screen appears in the event of a transient insulation fault:



Acknowledge the transient insulation fault by pressing the  contextual menu button.

## Special Status Screens

### Presentation

The special status screens are displayed depending on events that occur during the product life. The screens depend on the event type but always trigger the red product status indicator light and the insulation alarm relay is active. If the preventive insulation alarm relay is configured in mirror mode, it is also triggered and no longer mirrors the insulation alarm relay.

### Over-Limit Capacitance Detection


**NOTE:** This screen is applicable for IM400/IM400C/IM400L.

The over-limit capacitance detection state is triggered when the capacitance of the monitored system becomes too high. For details on the Vigilohm IM400 limits, refer to the product performances. In case of detected over-limit capacitance, the Vigilohm IM400 is no longer able to monitor the IT system.

Power Circuit or Control Circuit	Photovoltaic Circuit	
	IM400-1700	IM400VA2

### Overvoltage


The overvoltage state is triggered when the voltage of the monitored system becomes too high. For details on the Vigilohm IM400 limits, refer to the product performances. In case of overvoltage, the Vigilohm IM400 is no longer able to monitor the IT system and automatically disconnects of the power system until the product is manually reset by briefly disconnecting the auxiliary power supply.



### Disconnected Injection Detection

The state of disconnected injection is triggered when the Vigilohm IM400 detects that the ground conductor or the injection wire is disconnected. In case of disconnected injection detected, the Vigilohm IM400 is no longer able to monitor the IT system.

If the **Disconnect Inj.** parameter in the **Ins. Alarm** menu is set to **ON**, the following screen displays:



If the **Disconnect Inj.** parameter is set to **OFF**, the Vigilohm IM400 displays **R > 10 MΩ**.

**Inoperative Product**

The inoperative product state is triggered when the Vigilohm IM400 is inoperative.



## Modifying Parameters

### Presentation

To modify any of the values, you must be familiar with how the interface menus are structured and the general navigation principles. For more information about how the menus are structured, refer to the Vigilohm IM400 menu structure (*see page 58*).

To modify the value of a parameter, follow either of the two methods described below:

- Select an item (value plus unit) in a list.
- Modify a numerical value, digit by digit.

The parameters listed below are the only ones where the numerical value can be modified:

- date
- time
- password
- Modbus address

### Selecting the Value in a List

To select a value in a list, use the  or  contextual menu buttons to scroll through the parameter values until you reach the desired value. Then press  to confirm the new parameter value.

### Modifying the Numerical Value

The numerical value of a parameter is made up of digits and it is the one on the far right that is selected by default.

To modify a numerical value, use the contextual menu buttons as described below:

-  allows you to modify the selected digit.
-  allows you to select the digit to the left of the one that is selected, or to loop back to the digit on the right.
-  confirms the new parameter value.

### Saving a Parameter

After you have confirmed the modified parameter, one of the two screens appears:

- If the parameter has been saved correctly, the screen displays **Saved** and then automatically reverts to the previous display.
- If the parameter has not been saved correctly, the screen displays **Error** and the editing screen remains active. It happens when:
  - a value is deemed to be out of range (for example the value is classed as forbidden),
  - there are several interdependent parameters.

### Exiting an Entry

To exit the current parameter entry, press the **ESC** button. The screen reverts to the previous display.

### Editing Protected Settings

You can set a password to limit access to configuration of Vigilohm IM400 parameters to authorized personnel only. When a password has been set, the information displayed by the device can be viewed but the parameter values cannot be edited.

The password is inactive by default. When password protection is enabled, the default password is 0000. If you want to change the factory value, you must enter a 4-digit password from 0000 to 9999 when editing a parameter.

The procedure for setting a password is the same as editing a numerical value.

Step	Action
1	Navigate to <b>MENU</b> → <b>Settings</b> → <b>Password</b> .
2	Select <b>Modify Password</b> . Press  to edit the new password digit by digit (editing starts from the digit furthest to the right).
3	Use  to increase the value of the digit. It will automatically roll over from 9 to 0. <b>NOTE:</b> Keep the  button pressed down to accelerate scrolling through the values.

Step	Action
4	Press  to move to the next digit. Pressing this button on the last digit (furthest left) loops you back to the first one.
5	Repeat steps 3 and 4 for all other digits.
6	Press  to save the new password. A message indicates that the password was saved successfully. The screen reverts to the previous one.
7	Select <b>Activation</b> . Press  .
8	Change value list to <b>ON</b> by pressing the  or  arrows. Validate the entry by selecting  . A message indicates that the parameter was saved successfully. <b>Result:</b> The password protection is now active.

The procedure for entering a password is similar to editing a numerical value.

Step	Action
1	Press the contextual menu navigation keys to navigate to the parameter to edit.
2	Press  . The screen to enter the password is displayed. The first (furthest left) digit is selected and ready to edit.
3	Use  to increase the value of the digit. It will automatically roll over from 9 to 0. <b>NOTE:</b> Keep the  button pressed down to accelerate scrolling through the values.
4	Press  to move to the next digit. Pressing this button on the last digit (furthest right) loops you back to the first one.
5	Repeat steps 3 and 4 for all other digits.
6	Press  to validate the password entry. If the password has been entered correctly, the protection system stays unlocked for 30 seconds or as long as you are editing parameters. If the password has been entered incorrectly, an error message is displayed and you must enter the password again. Use the <b>ESC</b> button to revert to the previous screen.

## Clock

### Description

Vigilohm IM400 uses the date and time parameter to time-tag the system insulation faults recorded.

The time must be set:

- whenever the power supply is interrupted,
- when switching from winter to summer time and back.

If the auxiliary power supply is interrupted, Vigilohm IM400 retains the date and time setting from immediately before the interruption.

### Icon

When Vigilohm IM400 is powered up, the clock icon flashes on the system monitoring screens to indicate that the clock needs to be set.

Pressing the top contextual button displays the clock setup screen.

### Setting

To set the date and time, refer to the procedure for modifying a numerical value (*see page 66*).

### Date/Time Format

The date is displayed in the format: dd.mm.yyyy.

The time is displayed using the 24-hour clock in the format: hh:mm.

### Screen Saver

The Screen Saver mode turns off the screen after 5 minutes of inactivity. You can activate the screen again by pressing any button.

## Insulation Fault Log

### Description

Vigilohm IM400 records the details of the 30 most recent insulation fault events that have triggered one of the 2 statuses below:

- preventive insulation alarm
- insulation alarm


Event 1 is the one that was recorded most recently and event 30 is the oldest recorded event.

The oldest event is deleted when a new event occurs. Due to the rolling buffer the Vigilohm IM400 may show 28 logs maximum. To reset all the events, select **Settings** → **Reset** → **Reset Logs**.

Using this information, the performance of the distribution system can be improved and maintenance work facilitated. It is also available through Modbus (*see page 71*).

### Insulation Fault Event Screen

The figure below shows the display elements associated with an insulation fault event:



Legend	Description
1	Insulation fault value recorded
2	Type of insulation fault recorded: insulation alarm, preventive insulation alarm, transient insulation alarm
3	Date and time when the insulation alarm fault, preventive insulation alarm, or transient insulation fault occurred
4	Date and time when the event disappeared: <ul style="list-style-type: none"> <li>•  Insulation alarm acknowledgment</li> <li>•  Disappearance of preventive insulation alarm or transient insulation alarm</li> </ul>
5	Number of events displayed
6	Total number of events recorded

## Trend Screens

### Presentation


Vigilohm IM400 records and can display curves of the average of the system insulation over the following durations:

- last hour (1 point every 2 minutes)
- last day (1 point per hour)
- last week (1 point per day)
- last month (1 point per day)
- last year (1 point per month)

The chart scale automatically adjusts to the shown data to optimize the display accuracy.

The curves show a general trend how the system insulation evolves over time. They are calculated from averages related to shorter or longer durations depending on the charts. So charts may not show transient insulation faults when they are smoothed over time.

### Trend Screen



Legend	Description
1	Trend
2	Current value of the insulation alarm threshold
3	Vertical dotted line: indicates a power interruption (duration undefined)
4	Squared area: indicates that the injection has been inhibited

---

# Chapter 5

## Communication via Modbus RS-485

---

### What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Configuring RS-485 Communication Port	72
Table of Modbus Functions	73
Modbus Registers Tables	74

## Configuring RS-485 Communication Port

### Communication Parameters

Before initiating any communication processes, configure the Modbus communication port via the HMI on Vigilohm IM400 selecting **Menu** → **Settings** → **Modbus**.

Parameters	Authorized values	Factory value
Address	1...247	1
Auto Config	ON / OFF	OFF
Baud rate	<ul style="list-style-type: none"> <li>● 4800 Baud</li> <li>● 9600 Baud</li> <li>● 19 200 Baud</li> <li>● 38 400 Baud</li> </ul>	19 200 Baud
Parity	<ul style="list-style-type: none"> <li>● Even</li> <li>● Odd</li> <li>● None</li> </ul>	Even

In point-to-point mode, when the device is directly connected to a computer, the reserved address 248 can be used to communicate with the device whatever the device internal address.

### Signaling of Communication Activity

The yellow  indicator light indicates the status of the activity on the Modbus RS-485 bus as follows:

If	Then
If the indicator light is flashing	Communication on the bus is active.
If the indicator light is off	There is no active communication between master and slave.

**NOTE:** The yellow indicator light flashes on every valid Modbus frame even if the Vigilohm IM400 is not addressed directly.

## Table of Modbus Functions

### Modbus Functions

Function code		Function name
Decimal	Hexadecimal	
3	0x03	Read Holding Registers <sup>(1)</sup>
4	0x04	Read Input Registers <sup>(1)</sup>
6	0x06	Write Single Register
8	0x08	Diagnostics
16	0x10	Write Multiple Registers
43 / 14	0x2B / 0x0D	Read Device Identification
43 / 15	0x2B / 0x0E	Get Date/Time
43 / 16	0x2B / 0x0F	Set Date/Time
98	0x62	Modbus/98 <sup>(2)</sup>
<b>(1)</b> The Read Holding and Read Input registers are identical		
<b>(2)</b> Refer to the Functional Safety Standards Compliance chapter for more details on the Modbus/98 function		

The read device identification request is as follows:

Number	Type	Value
0	VendorName	Schneider Electric
1	ProductCode	IM400
2	MajorMinorRevision	vX.Y.Z
3	VendorURL	www.schneider-electric.com
4	ProductName	Insulation Monitoring Device
5	ModelName	IM400

The product answers any types of requests (basic, regular, extended).

## Modbus Registers Tables

### Table Format

Modbus register tables have the following columns:

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					

- **Register address:** Address of register encoded in the Modbus frame, in hexadecimal (hex) and decimal (dec) formats
- **Register number:** corresponds to the Register Address + 1, in hexadecimal (hex) and decimal (dec) formats
- **RW:** Whether the register is read only (R) or read/write (RW)
- **Unit:** The unit the information is expressed in
- **Type:** The encoding data type
- **Range:** The permitted values for this variable, usually a subset of what the format allows
- **Description:** Provides information about the register and the values that apply

### System Status

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x0064	100	0x0065	101	R	–	Uint16	<ul style="list-style-type: none"> <li>• 17000 - IM10</li> <li>• 17001 - IM10H</li> <li>• 17002 - IM20</li> <li>• 17003 - IM20H</li> <li>• 17004 - IM400</li> <li>• 17005 - IM400C</li> <li>• 17006 - IM400L</li> <li>• 17007 - IM400THR</li> <li>• 17008 - IM400LTHR</li> </ul>	Device identifier
0x0066... 0x0067	102...103	0x0067...0x0 068	103...104	R	–	Uint16	Encoded version X.Y.Z	Firmware version X.Y.Z: <ul style="list-style-type: none"> <li>• X represents the primary revision number, which is encoded in the most significant byte of register 102.</li> <li>• Y represents the secondary revision number, which is encoded in the least significant byte of register 102.</li> <li>• Z represents the quality revision number, which is encoded in register 103.</li> </ul>
0x0069... 0x006C	105...108	0x006A...0x0 06D	106...109	RW	–	–	–	Date/Time (TI081 format <i>(see page 83)</i> )

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x006D	109	0x006E	110	R	–	Uint16	–	Product status: <ul style="list-style-type: none"> <li>● Most significant byte = error code</li> <li>● Least significant byte = product status               <ul style="list-style-type: none"> <li>○ 0x00 - Normal operation</li> <li>○ 0x01 - Self-test</li> <li>○ 0x02 - Insulation fault</li> <li>○ 0x03 - Disconnected injection detected</li> <li>○ 0x04 - Over-limit capacitance</li> <li>○ 0x05 - Inoperative product</li> <li>○ 0x06 - Injection disabled</li> <li>○ 0x07 - Overvoltage</li> </ul> </li> </ul>

### Monitoring

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x03E8	1000	0x03E9	1001	R	Ohm	Float32	–	Resistance. When injection is inhibited and during self-test, the valueNaN (Not a Number) 0xFFC00000 is returned.
0x03EA	1002	0x03EB	1003	R	F	Float32	–	Capacitance. When injection is inhibited and during self-test, the valueNaN (Not a Number) 0xFFC00000 is returned.
0x03F0	1008	0x03F1	1009	R	–	Uint16	<ul style="list-style-type: none"> <li>● 0 = Injection activated</li> <li>● 1 = Injection deactivated</li> </ul>	Injection status
0x03F1	1009	0x03F2	1010	R	V	Float32	–	RMS Voltage to ground. When injection is inhibited and during self-test, the valueNaN (Not a Number) 0xFFC00000 is returned.
0x03F3	1011	0x03F4	1012	R	–	Uint16	<ul style="list-style-type: none"> <li>● 0 = equal</li> <li>● 1 = Under</li> <li>● 2 = Over</li> <li>● 3 = UnderStrict</li> <li>● 4 = OverStrict</li> </ul>	R equality
0x03F4	1012	0x03F5	1013	R	–	Uint16	<ul style="list-style-type: none"> <li>● 0 = equal</li> <li>● 1 = Under</li> <li>● 2 = Over</li> <li>● 3 = UnderStrict</li> <li>● 4 = OverStrict</li> </ul>	C equality

## Insulation Alarm Status

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x044C	1100	0x044D	1101	R	–	UInt16	<ul style="list-style-type: none"> <li>● 0 = No insulation alarm</li> <li>● 1 = Insulation alarm active</li> <li>● 2 = Preventive insulation alarm active</li> <li>● 4 = Transient insulation alarm</li> <li>● 8 = Insulation alarm acknowledged</li> </ul>	Insulation alarm status

## Trending Data

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x04B0	1200	0x04B1	1201	R	–	UInt16	Hour trending	Number of new records in trending buffer not yet read by the Modbus master
0x04B1	1201	0x04B2	1202	R	–	UInt16	Day trending	Number of new records in trending buffer not yet read by the master
0x04B2	1202	0x04B3	1203	R	–	UInt16	Week trending	Number of new records in trending buffer not yet read by the master
0x04B3	1203	0x04B4	1204	R	–	UInt16	Month trending	Number of new records in trending buffer not yet read by the master
0x04B4	1204	0x04B5	1205	R	–	UInt16	Year trending	Number of new records in trending buffer not yet read by the master
0x04BA	1210	0x04BB	1211	R	–	Float32	Hour value	Reading hour values. Each reading decrements the counter at address 1200.
0x04BC	1212	0x04BD	1213	R	–	UInt16	Hour value status	Status: <ul style="list-style-type: none"> <li>● 0x0000 - Data not initialized</li> <li>● 0x0001 - Data invalid</li> <li>● 0x0002 - Data valid</li> <li>● 0x0003 - Power supply loss after this value</li> <li>● 0x0004 - Injection after this value</li> <li>● 0x0005 - Power supply loss and injection disable after this value</li> </ul>
0x04BD	1213	0x04BE	1214	R	–	Float32	Day value	Reading day values. Each reading decrements the counter at address 1201.

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x04BF	1215	0x04C0	1216	R	–	Uint16	Day value status	Status: <ul style="list-style-type: none"> <li>● 0x0000 - Data not initialized</li> <li>● 0x0001 - Data invalid</li> <li>● 0x0002 - Data valid</li> <li>● 0x0003 - Power supply loss after this value</li> <li>● 0x0004 - Injection disable after this value</li> <li>● 0x0005 - Power supply loss and injection disable after this value</li> </ul>
0x04C0	1216	0x04C1	1217	R	–	Float32	Week value	Reading week values. Each reading decrements the counter at address 1202.
0x04C2	1218	0x04C3	1219	R	–	Uint16	Week value status	Status: <ul style="list-style-type: none"> <li>● 0x0000 - Data not initialized</li> <li>● 0x0001 - Data invalid</li> <li>● 0x0002 - Data valid</li> <li>● 0x0003 - Power supply loss after this value</li> <li>● 0x0004 - Injection disable after this value</li> <li>● 0x0005 - Power supply loss and injection disable after this value</li> </ul>
0x04C3	1219	0x04C4	1220	R	–	Float32	Month value	Reading month values. Each reading decrements the counter at address 1203.
0x04C5	1221	0x04C6	1222	R	–	Uint16	Month value status	Status: <ul style="list-style-type: none"> <li>● 0x0000 - Data not initialized</li> <li>● 0x0001 - Data invalid</li> <li>● 0x0002 - Data valid</li> <li>● 0x0003 - Power supply loss after this value</li> <li>● 0x0004 - Injection disable after this value</li> <li>● 0x0005 - Power supply loss and injection disable after this value</li> </ul>
0x04C6	1222	0x04C7	1223	R	–	Float32	Year value	Reading year values. Each reading decrements the counter at address 1205.
0x04C8	1224	0x04C9	1225	R	–	Uint16	Year value status	Status: <ul style="list-style-type: none"> <li>● 0x0000 - Data not initialized</li> <li>● 0x0001 - Data invalid</li> <li>● 0x0002 - Data valid</li> <li>● 0x0003 - Power supply loss after this value</li> <li>● 0x0004 - Injection disable after this value</li> <li>● 0x0005 - Power supply loss and injection disable after this value</li> </ul>

### Diagnostic

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x07D0	2000	0x07D1	2001	W	–	Uint16	–	Write 0xA456 to start self-test

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x07D1... 0x07D4	2001...2004	0x07D2... 0x07D5	2002...2005	R	–	–	–	Total uptime since first power-up of product. Registers correspond to (result - 01/01/2000) = total uptime. TI081 date format (see page 83).
0x07D5	2005	0x07D6	2006	R	–	Uint32	–	Total number of power cycles since first power-up of the product
0x0802	2050	0x0803	2051	W	–	Uint16	–	Write 0x1919 to reset factory settings (default factory settings)
0x0803	2051	0x0804	2052	W	–	Uint16	–	Write 0xF0A1 to reset all logs
0x0804	2052	0x0805	2053	W	–	Uint16	–	Write 0x25AB to reset all graphs

## CRC

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x09C4	2500	0x09C5	2501	R	–	Uint32	–	Application CRC value
0x09C6	2502	0x09C7	2503	R	–	Uint32	–	Boot CRC value

## Settings

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x0BB7	2999	0x0BB8	3000	R	–	Uint16	–	Total number of settings changed since first power-up. Incremented by 1 for each change of one or several parameters.
0x0BB8	3000	0x0BB9	3001	RW	–	Uint16	<ul style="list-style-type: none"> <li>0 = Normally open</li> <li>1 = Normally closed</li> </ul>	Injection inhibition input configuration. Factory value: 0 (Normally open).
0x0BB9	3001	0x0BBA	3002	RW	–	Uint16	<ul style="list-style-type: none"> <li>1 = Standard connection</li> <li>2 = Failsafe</li> </ul>	Insulation alarm relay logic command. Factory value: 2 (Failsafe).
0x0BBA	3002	0x0BBB	3003	RW	Ohm	Uint32	40 Ω...500 kΩ	Insulation alarm threshold. Factory value: 1 kΩ.
0x0BBC	3004	0x0BBD	3005	RW	Ohm	Uint32	<ul style="list-style-type: none"> <li>1 kΩ...1 MΩ</li> <li>0xFFFFFFFF = OFF</li> </ul>	Preventive insulation alarm threshold. OFF is used to deactivate the preventive insulation alarm. Factory value: 0xFFFFFFFF (Deactivated).
0x0BBF	3007	0x0BC0	3008	RW	s	Uint16	0...7200	Insulation alarm time delay. Factory value: 0.

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x0BC0	3008	0x0BC1	3009	RW	s	Uint16	For IM400/IM400C/IM400L: <ul style="list-style-type: none"> <li>● 0 = Short (4 s)</li> <li>● 1 = Medium (40 s)</li> <li>● 2 = Long (400 s)</li> </ul> For IM400THR/IM400LTHR: <ul style="list-style-type: none"> <li>● 0 = 2 s</li> <li>● 1 = 20 s</li> <li>● 2 = 200 s</li> </ul>	Network filtering. For IM400/IM400C/IM400L Factory value: 1 (40 s). For IM400THR/IM400LTHR: Factory value: 1 (20 s).
0x0BC1	3009	0x0BC2	3010	RW	Hz	Uint16	<ul style="list-style-type: none"> <li>● 0 (for DC system)</li> <li>● 50</li> <li>● 60</li> <li>● 400</li> </ul>	System frequency. Factory value: 50 Hz.
0x0BC6	3014	0x0BC7	3015	RW	–	Uint16	0000...9999	Password. Factory value: 0000.
0x0BC7	3015	0x0BC8	3016	RW	–	Uint16	<ul style="list-style-type: none"> <li>● 0 = OFF</li> <li>● 1 = ON</li> </ul>	Password protection. Factory value: 0 (password protection deactivated).
0x0BC8	3016	0x0BC9	3017	RW	–	Uint16	<ul style="list-style-type: none"> <li>● 0 = English</li> <li>● 1 = French</li> <li>● 2 = Spanish</li> <li>● 3 = Russian</li> <li>● 4 = Chinese</li> <li>● 5 = Italian</li> <li>● 6 = German</li> <li>● 7 = Portuguese</li> </ul>	Interface language. Factory value: 0 (English).
0x0BC9	3017	0x0BCA	3018	RW	%	Uint16	10...100	Display contrast. Factory value: 50.
0x0BCA	3018	0x0BCB	3019	RW	%	Uint16	10...100	Display brightness. Factory value: 100.
0x0BCB	3019	0x0BCC	3020	RW	–	Uint16	For IM400/IM400L: <ul style="list-style-type: none"> <li>● 0 = None</li> <li>● 1 = HV1700</li> <li>● 2 = PHT1000</li> <li>● 3 = VA2</li> </ul> For IM400C: <ul style="list-style-type: none"> <li>● 0 = None</li> <li>● 1 = HV1700C</li> <li>● 2 = PHT1000</li> <li>● 3 = VA2</li> </ul> For IM400THR/IM400LTHR: <ul style="list-style-type: none"> <li>● 4 = None</li> <li>● 5 = THR</li> </ul>	Voltage adaptor. For IM400/IM400L/IM400C: Factory value: 0 (no plate). For IM400THR/IM400LTHR: Factory value: 5 (THR).
0x0BCC	3020	0x0BCD	3021	RW	–	Uint16	<ul style="list-style-type: none"> <li>● 1 = Standard connection</li> <li>● 2 = Failsafe</li> <li>● 3 = Mirror</li> </ul>	Preventive insulation alarm relay logic command. Factory value: 2 (failsafe).
0x0BCD	3021	0x0BCE	3022	RW	s	Uint16	0...7200	Preventive insulation alarm time delay

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x0BCE	3022	0x0BCF	3023	RW	-	Uint16	<ul style="list-style-type: none"> <li>● 0 = OFF</li> <li>● 1 = ON</li> </ul>	Insulation alarm relay reactivation. Factory value: 0. ON = relay triggers 3 s if insulation fault disappears in insulation alarm acknowledgement mode
0x0BCF	3023	0x0BD0	3024	RW	-	Uint16	<ul style="list-style-type: none"> <li>● 0 = OFF</li> <li>● 1 = ON</li> </ul>	Insulation alarm relay acknowledgement. Factory value: 1.
0x0BD0	3024	0x0BD1	3025	RW	-	Uint16	<p>For IM400/IM400L/IM400C:</p> <ul style="list-style-type: none"> <li>● 0 = Min (15 V)</li> <li>● 1 = Low (33 V)</li> <li>● 2 = Medium (120 V)</li> <li>● 3 = Max (150 V) (with IM400-1700 or IM400VA2 voltage adaptor)</li> </ul> <p>For IM400THR/IM400LTHR:</p> <ul style="list-style-type: none"> <li>● 0 = 20V</li> <li>● 1 = 40V</li> <li>● 2 = 60V</li> <li>● 3 = 80V</li> </ul>	Injection voltage. Factory value: 2.
0x0BD1	3025	0x0BD2	3026	RW	-	Uint16	<p>For IM400/IM400L:</p> <ul style="list-style-type: none"> <li>● 0 = Power (Industry)</li> <li>● 1 = Control circuits</li> </ul> <p>For IM400C:</p> <ul style="list-style-type: none"> <li>● 0 = Power (Industry)</li> <li>● 1 = Control circuits</li> <li>● 2 = Photovoltaic</li> </ul> <p>For IM400THR/IM400LTHR:</p> <ul style="list-style-type: none"> <li>● 3 = THR</li> </ul>	Customer application. For IM400/IM400L/IM400C: Factory value: 0. For IM400THR/IM400LTHR: Factory value: 3.
0x0BD2	3026	0x0BD3	3027	RW	-	Uint16	<ul style="list-style-type: none"> <li>● 0 = OFF</li> <li>● 1 = ON</li> </ul>	Disconnected injection detection. Factory value: 0.
0x0BD3	3027	0x0BD4	3028	RW	-	Uint16	<ul style="list-style-type: none"> <li>● 0 = OFF</li> <li>● 1 = Alarm</li> <li>● 2 = Prev Alarm</li> </ul>	Insulation fault locating. Factory value: 0.
0x0BD5	3029	0x0BD6	3030	RW	-	Uint16	<ul style="list-style-type: none"> <li>● 0 = OFF</li> <li>● 1 = ON</li> </ul>	Self-test: test with relays. Factory value: 1.
0x0BD6	3030	0x0BD7	3031	RW	Ω	Uint32	<ul style="list-style-type: none"> <li>● 0.1...500 kΩ</li> <li>● 0xFFFFFFFF = OFF</li> </ul>	Grounding resistance for impedant IT systems (HRG). Factory value: 0xFFFFFFFF (disabled).
0x0BD8	3032	0x0BD9	3033	RW	-	Uint16	<ul style="list-style-type: none"> <li>● 0 = OFF</li> <li>● 1 = ON</li> </ul>	Alarm when injection inhibition is active. Factory value: 0.

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x0BD9	3033	0x0BDA	3034	RW	-	Uint16	<ul style="list-style-type: none"> <li>0 = OFF</li> <li>1 = ON</li> </ul>	Screensaver activation. Factory value: 0.
0x0BDA	3034	0x0BDB	3035	RW	s	Uint16	30...3600s	Screensaver delay. Factory value: 300s (5 mins).
0x0BDB	3035	0x0BDC	3036	RW	s	Uint16	0=OFF, 1=ON	Inhibition Input. Factory value: 0.
0x0BDC	3036	0x0BDD	3037	RW	Ohm	Uint16	0...50K ohm	Transformer primary DC resistance. Factory value: 0. <b>NOTE:</b> Applicable for IM400THR/IM400LTHR
0x0BDD	3037	0x0BDE	3038	RW	-	Uint16	<ul style="list-style-type: none"> <li>0</li> <li>1</li> <li>3</li> </ul>	Number of transformers. Factory value: 0. <b>NOTE:</b> Applicable for IM400THR/IM400LTHR
0x0BDE	3038	0x0BDF	3039	RW	Ohm	Float32	-	Adapter offset resistance. Factory value: 0. <b>NOTE:</b> Applicable for IM400THR/IM400LTHR

### Functional Safety Standards Compliance

This section is only accessible in write mode only using the Modbus/98 protocol (Functional Safety Standards Compliance, *(see page 91)*). It is accessible in read only mode using standard modbus.

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x0FA0	4000	0x0FA1	4001	RW	-	Uint16	0=OFF, 1=ON	Disable standard Modbus write. Factory value: 0.

### Log

Address		Register number		RW	Unit	Type	Range	Description
hex	dec	hex	dec					
0x4E20	20000	0x4E21	20001	R	-	Uint16	1...60	Number of event records
0x4E21	20001	0x4E22	20002	R	-	Uint16	-	Number of the most recent record
0x4E22... 0x4E2D	20002... 20013	0x4E23... 0x4E2E	20003... 20014	R	-	Record	-	Record 1
0x4E2E... 0x4E39	20014... 20025	0x4E2F... 0x4E3A	20015... 20026	R	-	Record	-	Record 2
...								
0x50E6... 0x50F1	20710... 20721	0x50E7... 0x50F2	20711... 20722	R	-	Record	-	Record 60

Each event is stored using two records:

- A primary record, which is created when the insulation alarm or preventive insulation alarm occurs. This contains the insulation value.
- A secondary record, which is created when the insulation alarm or preventive insulation alarm disappears. This contains the type of event (acknowledged insulation alarm, transient insulation alarm, preventive insulation alarm).

The two records are logged consecutively.

## Description of an Event Record in the Log

Register	Unit	Type	Range	Description
Word 1	–	Uint16	1...65535	Event record number
Word 2 Word 3 Word 4 Word 5	–	Uint64	–	Time tagging of event (using the same code as for the product date/time)
Word 6 Word 7	–	Uint32	<ul style="list-style-type: none"> <li>● 0...1</li> <li>● 0x40, 0x10</li> <li>● 1000, 1100</li> </ul>	Record identifier: <ul style="list-style-type: none"> <li>● Word 6, most significant byte: Information for primary/secondary record. This field assumes a value of 1 for the primary record and a value of 0 for the secondary record.</li> <li>● Word 6, least significant byte: Type of data stored in the <b>Value</b> field</li> <li>● Word 7: Address of the Modbus register that is the source of the data in the <b>Value</b> field</li> </ul>
Word 8 Word 9 Word 10 Word 11	–	Uint64	–	Depending on the type of record (primary or secondary): <ul style="list-style-type: none"> <li>● Insulation resistance value (in ohms) at the time of the event occurrence (encoded in Float32 in the last two registers)</li> <li>● Insulation alarm type (encoded in Uint16 in the last register)</li> </ul>
Word 12	–	Uint16	1...65534	Primary/secondary record identifier for event: <ul style="list-style-type: none"> <li>● In the case of a primary record for an event, this identifier is an odd integer; numbering starts at 1 and the number is incremented by 2 for each new event.</li> <li>● In the case of a secondary record for an event, this identifier is equal to the primary record identifier plus 1.</li> </ul>

## Example of an Event

The two records below represent an insulation alarm that occurred at 12:00 on October 1, 2010 and was acknowledged at 12:29.

Record number: 1

Address		Register number		Unit	Type	Value	Description
hex	dec	hex	dec				
0x4E22	20002	0x4E23	20003	–	Uint16	1	Record number
0x4E23	20003	0x4E24	20004	–	Uint64	<ul style="list-style-type: none"> <li>● 10</li> <li>● 0</li> <li>● 10</li> <li>● 1</li> <li>● 12</li> <li>● 0</li> <li>● 0</li> </ul>	Date when insulation alarm occurred (October 1, 2010, 12:00)
0x4E27	20007	0x4E28	20008	–	Uint32	<ul style="list-style-type: none"> <li>● 1</li> <li>● 0x40</li> <li>● 1000</li> </ul>	Record identifier: <ul style="list-style-type: none"> <li>● Primary record plus secondary record</li> <li>● Float32 value (insulation resistance)</li> <li>● Value of register 1000 (register for insulation resistance monitoring)</li> </ul>
0x4E29	20009	0x4E2A	20010	Ohm	Uint64	10000	Insulation resistance value at the time of the insulation alarm
0x4E2D	20013	0x4E2E	20014	–	Uint16	1	Secondary record identifier for event

Record number: 2

Address		Register number		Unit	Type	Value	Description
hex	dec	hex	dec				
0x4E2E	20014	0x4E2F	20015	–	Uint16	2	Record number
0x4E2F	20015	0x4E30	20016	–	Uint64	<ul style="list-style-type: none"> <li>● 10</li> <li>● 0</li> <li>● 10</li> <li>● 1</li> <li>● 12</li> <li>● 29</li> <li>● 0</li> </ul>	Date when insulation alarm disappeared (October 1, 2010, 12:29)
0x4E33	20019	0x4E34	20020	–	Uint32	<ul style="list-style-type: none"> <li>● 1</li> <li>● 0x10</li> <li>● 1100</li> </ul>	Record identifier: <ul style="list-style-type: none"> <li>● Secondary record</li> <li>● Uint16 value (insulation alarm acknowledged)</li> <li>● Value of register 1100 (insulation alarm status register)</li> </ul>
0x4E35	20021	0x4E36	20022	–	Uint64	8	Value of insulation alarm register at the time of insulation alarm acknowledgement
0x4E39	20025	0x4E3A	20026	–	Uint16	2	Secondary record identifier for event

### Date and Time

The following structure is used for date-time information exchange using Modbus protocol.

The date/time are encoded in 8 bytes as follows:

b15	b14	b13	b12	b11	b10	b09	b08	b07	b06	b05	b04	b03	b02	b01	b00	Word
0	0	0	0	0	0	0	0	R4	Y	Y	Y	Y	Y	Y	Y	Word 1
0	0	0	0	M	M	M	M	WD	WD	WD	D	D	D	D	D	Word 2
SU	0	0	H	H	H	H	H	iV	0	mn	mn	mn	mn	mn	mn	Word 3
ms	Word 4															

- R4: Reserved bit (reserved by IEC870-5-4), set to 0
- Y - Years
  - 1 byte
  - Value from 0...127 (1/1/2000 to 31/12/2127)
- M - Months
  - 1 byte
  - Value from 1...12
- D - Days
  - 1 byte
  - Value from 1...31
- H - Hours
  - 1 byte
  - Value from 0...23
- mn - Minutes
  - 1 byte
  - Value from 0...59
- ms - Milliseconds
  - 2 byte
  - Value from 0...59999

The following fields are in **CP56Time2a** standard and are considered as optional:

- WD - Week Day
  - If not used, set to 0 (1 = Sunday, 2 = Monday...)
  - Value from 1...7
- SU - Summertime

- If not used, set to 0 (0 = standard time, 1 = summertime)
  - Value from 0...1
- iV - Validity of the information contained in the structure
  - If not used, set to 0 (0 = valid, 1 = not valid or not synchronized in system)
  - Value from 0...1

This information is encoded in binary form.

---

# Chapter 6

## Maintenance and Troubleshooting

---

### What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Safety Precautions	86
Commissioning	87
Maintenance and Troubleshooting	88

## Safety Precautions

### Safety Precautions

The following safety precautions must be thoroughly implemented before commissioning or attempting to repair electrical equipment or carry out maintenance. Carefully read and follow the safety precautions described below.

#### **DANGER**

##### **HAZARD OF ELECTRIC SHOCK, ARC FLASH OR BURNS**

- Wear suitable personal protective equipment and follow the currently applicable electrical safety instructions. See, for example, standard NFPA 70E when carrying out work in the USA.
- Only qualified personnel should maintain this equipment. Such work should be performed only after reading all the installation instructions.
- Turn off all power supplying this equipment before working on or inside it.
- NEVER work alone.
- Beware of potential hazards and wear personal protective equipment.

**Failure to follow these instructions will result in death or serious injury.**

#### ***NOTICE***

##### **HAZARD OF PRODUCT DAMAGE**

- Never open the Vigilohm unit.
- Do not attempt to repair any components in the Vigilohm range, either in the unit or an accessory.

**Failure to follow these instructions can result in equipment damage.**

## Commissioning

### Validating Correct Insulation Monitoring With Exclusion Management

In order to have proper insulation monitoring of the electrical power system, it is important that it is monitored by one and only one insulation monitoring device at a time.

For most of the systems that do not include multiple incomers or coupling of multiple busbars this is easily achieved as there is only one IMD in the system permanently active.

For systems with multiple incomers or power busbar coupling, the monitoring system embeds several Vigilohm IMDs as explained in the Injection Inhibition Input and Exclusion Management section (*see page 50*). The exclusion/activation of each IMD according to the electrical power system configuration is managed through the injection inhibit contact. It is then important at commissioning to validate that insulation of every part of the electrical power system is monitored by an active IMD, and that the management of exclusion/activation of each IMD does not lead to a part of the power system monitored by more than one IMD or by no IMD. This in order to avoid insulation fault not being reported.

### Insulation Metering and Insulation Fault Detection Testing

To verify that Vigilohm IM400 is correctly installed and configured:

- It is recommended to check the installation by connecting a known impedance between wiring terminals 1 and 3 of the Vigilohm IM400 (10 k $\Omega$ ) and verifying that the impedance is correctly measured. For this test, do not connect Vigilohm IM400 to the monitored network.
- It is recommended to check the insulation fault detection by strapping wiring terminals 1 and 3 of Vigilohm IM400 (creating a 0  $\Omega$  insulation fault). For this test, do not connect Vigilohm IM400 to the monitored network.

### Insulation Alarm Relay Wiring Testing

To check that the insulation alarm relay is correctly wired in the installation, it is recommended to perform a device test with relay.

### Disconnected Injection Detection

If required in the application enable the disconnected injection detection parameter so that Vigilohm IM400 continuously performs this checking, and reports any connection or wiring issue.

The Vigilohm IM400 is delivered with the disconnected injection detection parameter set to **OFF**. This setting helps avoiding an undesired **Disconnected Injection Detected** message from appearing when installing and commissioning the device before connecting it to the power system and loads.

According to the system or application requirements, it may be needed to enable the disconnected injection detection parameter (setting it to **ON**) when executing the final commissioning. Thus the Vigilohm IM400 can continuously perform this checking during operation and report any injection connection or wiring issue.

### HV1/HV2 Wiring Testing

The connection between Vigilohm IM400 and the voltage adaptors IM400-1700 or PHT1000 or IM400VA2 is key for a correct behavior of IM400.

It is recommended to check the wiring of HV1 and HV2 wiring terminals to the voltage adaptor. It can be done by connecting a known impedance (for example, 10 k $\Omega$ ) between IM400-1700 wiring terminal 1 and IM400 wiring terminal 3, or between PHT1000 wiring terminal 3 and Vigilohm IM400 wiring terminal 3, or between IM400VA2 wiring terminal 5 / terminal 1 (connecting terminal 5 and 1 together) and IM400 wiring terminal 3.

Check that Vigilohm IM400 correctly measures.

For this test, do not connect IM400-1700 or PHT1000 or IM400VA2 to the monitored power system.

### Protection Password Setting

To avoid any unintended operation by not authorized or untrained personnel, it is recommended to set the protection password.

## Maintenance and Troubleshooting


### Product Status Indicator Light

The red product status indicator light indicates an error relating to one of the following:

- interruption of the injection circuit
- self-test not OK
- inoperative product
- over-limit capacitance for IM400:
  - C > 500 µF
  - C > 2,000 µF with IM400-1700 voltage adaptor or C > 5,000µF with IM400VA2 voltage adaptor in photovoltaic application

### Interruption of the Injection Circuit

If the injection circuit of the Vigilohm is interrupted, the display shows the message below and starts flashing:



### Self-Test

The Vigilohm performs a series of self-tests on start-up, and then at regular intervals during operation to detect any potential inoperations in its internal and external circuits. For more information on the self-test function, refer to the relevant section ([see page 56](#)).

### Troubleshooting

The table describes the potential problems and their probable causes. It also indicates the checks that can be carried out or provides possible solutions for each scenario. If you are still unable to resolve a problem after consulting the table, contact your Schneider Electric regional sales representative for assistance.

Potential Problem	Probable Cause	Possible Solution
The device displays nothing when switched on.	The device is not being supplied.	Check the auxiliary supply is present.
	The auxiliary supply does not comply.	Check the value of the auxiliary voltage: U = 110...480 Vac.
The device signals an insulation fault, but your system shows no signs of abnormal behavior.	The insulation fault alarm threshold is not appropriate.	Check the value of the insulation alarm threshold. Modify the insulation alarm threshold if necessary.
	The preventive insulation fault alarm threshold is not appropriate.	Check the value of the preventive insulation alarm threshold. Modify the preventive insulation alarm threshold if necessary.
You deliberately create an insulation fault, but the device does not detect it.	The resistance value used to simulate the insulation fault is greater than the value of the fault threshold.	Use a resistance value that is lower than the insulation alarm threshold or modify the insulation alarm threshold.
	The insulation fault is not detected between neutral and ground.	Start again verifying that you are between neutral and ground.
The product status indicator light is red and the display shows <b>Disconnected Injection Detected</b> .	The Vigilohm injection circuit is cut off.	<ul style="list-style-type: none"> <li>● Check the connection on the injection terminal block (wiring terminals 1 and 3) and restart the self-test.</li> <li>● Disable the function during the commissioning.</li> </ul>
	The power system being small, the Vigilohm IM400 interprets the low capacitance and high resistance of the power system as a disconnected injection.	
The product status indicator light is red and the display indicates that an error occurred during the self-test.	The Vigilohm injection circuit is cut off.	Briefly disconnect the auxiliary power supply for the Vigilohm.

Potential Problem	Probable Cause	Possible Solution
Although the Vigilohm is being supplied with power, the product status indicator light does not light up.	Inoperative indicator light.	Restart the self-test and check that the product status indicator light lights up briefly.
The insulation alarm indicator light does not light up in the event of an insulation fault.	Inoperative indicator light.	Restart the self-test and check that the insulation alarm indicator light lights up briefly.



---

# Chapter 7

## Functional Safety Standards Compliance

---

### ***NOTICE***

#### **LOSS OF FUNCTIONAL SAFETY STANDARDS COMPLIANCE**

The following chapter helps in configuring and operating IM400 in compliance with UL1998 and IEC60730-1 Annex H. Failure to configure and operate IM400 correctly may result in unexpected product behavior and loss of functional safety standards compliance.

**Failure to follow these instructions can result in equipment damage.**

#### **What Is in This Chapter?**

This chapter contains the following topics:

<b>Topic</b>	<b>Page</b>
Safety Standards Compliance Requirements	92
Product Installation and Wiring	93
Commissioning for Functional Safety Standards Compliance	95

## Safety Standards Compliance Requirements

### Introduction



The Vigilohm IM400C is certified UL-FS under the UL1998:2004 (STANDARD FOR SOFTWARE IN PROGRAMMABLE COMPONENTS) and UL991:2004 (UL Standard for Tests for Safety-Related Controls Employing Solid-State Devices) and IEC60730-1:2013+AMD1:2015 Annex H (Software Class B). This certification provides compliance with UL1741, CRD dated January 28, 2010, clauses 109-112 when the Vigilohm IM400C is installed and used in accordance with the related requirements.

### Scope

The Vigilohm IM400C and accessories (voltage adaptors) certification is valid if the installation and wiring of the system abides with the description below:

### Product Setup

To comply with the Functional Safety Standards requirements, the product must be configured using the following parameters, accessible by selecting:

**Menu** → **Settings** → **I/O Config** or Using Modbus/98 protocol (*see page 95*).

Setting	Description	Value
Ins. Al. Relay	Insulation Alarm Relay	<b>FS</b>
Prev. Al. Rel	Preventive Insulation Alarm Relay	<b>Mirror</b>
Inhibit. Input	Injection Inhibition Input	<b>N.O. or OFF</b>
Ack Inhibit.	Acknowledgement of the Inhibition signal	<b>ON</b>
Ack Al. Relay	Allow triggering relays when acknowledging alarm	<b>OFF</b>
Corr. Fault. Signal	Allow 3 s signal when insulation fault disappears	<b>OFF</b>
Test w. Relays	Toggle Relays during manual auto test	<b>OFF</b>

For detailed information about these parameters, refer to the Monitoring the System Insulation (*see page 37*) section.

## Product Installation and Wiring

### Relays


The IM400C provides a configuration option to help comply with the safety and application standards. The preventive alarm relay can be used as a mirrored actuator in coordination with the insulation alarm relay to help provide a global safety function (by means of inverted redundancy).

This function is activated through a relay setting called **Mirror Mode**:

**Menu → Settings → I/O Config → Prev. Al. Rel → Mirror.**

**NOTE:** When this mode is activated, the Preventive Insulation Alarm is only signaled through the white led and Modbus communication.

Once activated, the preventive alarm relay mirrors the alarm relay in inverted logic. In case of a product deficiency or a power outage, both relays are de-energized and drop to the same level, as shown below:



This allows you to easily separate an Insulation Fault signal from an Inoperative Product signal by implementing a series of simple wiring (or connection to a PLC).

### Status Input


Enabling the **Ack Inhibit** (Acknowledge Inhibition) option activates the trigger of an alarm when the injection inhibition is activated. The Acknowledge Inhibition option is detailed in the Injection Inhibition Input and Exclusion Management ([see page 50](#)).

It allows the system in which the IMD is installed to detect errors from the injection inhibition command (external wiring and internal components).

If the installation does not require the use of exclusion management or if the system implements the Modbus/98 protocol detailed below, an OFF option allows you to disable the Injection Inhibition input, providing a complete functional isolation. The electrical state changes on this input are then ignored (Injection inhibition input option OFF, ([see page 50](#)))

**PLC**

For the system to detect all the product states, the IMD must be connected to a PLC or equivalent device, as shown in the connection diagrams. For details wiring instructions, refer to the relevant section (see page 93).



- A** Preventive insulation alarm relay
- B** Insulation alarm relay
- C** Injection inhibition

For the PLC to cover the state of all the products the configuration below must be implemented:

Operation		Injection Inhibition Digital Output 1	Insulation Alarm Relay Digital Input 1	Preventive Insulation Alarm Relay Digital Input 2
Normal Operation	No Insulation Fault / Preventive Insulation Alarm	Open	Closed	Open
	Insulation Alarm	Open	Open	Closed
	Injection Disabled	Closed	Open	Closed
Inoperative Product	Status Input issue	Closed	Closed	Open
	Inoperative Product	–	Closed	Closed
	Inoperative Product	–	Open	Open

## Commissioning for Functional Safety Standards Compliance

### Introduction

In an Functional Safety Standards-compliant installation, the complete device and system setup must be tested before deployment of the installation.

### Commissioning Process

Stage	Description
1	Validate that the device wiring is identical to the description in the Product Installation and Wiring ( <i>see page 93</i> ) section.
2	The device settings must be identical to the description in the Product Setup ( <i>see page 92</i> ) section.
3	Validate the insulation monitoring with exclusion management.

### Validating Correct Device Setup and Wiring

Make sure that the exclusion logic is implemented in the PLC or the control circuit to ensure a correct insulation alarm detection.

### Validating Correct Insulation Monitoring with Exclusion Management

Make sure that the exclusion logic is implemented in the PLC or the control circuit to ensure a correct insulation alarm detection.

Refer to the general commissioning section for details about this topic (*see page 87*).

### Insulation Monitoring and Insulation Fault Detection Testing

**NOTE:** The following test must be done in case the Modbus/98 protocol is not used.

- When product is powered off, make sure that inputs of the PLC or the control circuit are as described in the PLC paragraph of the Product Installation and Wiring section (*see page 94*).
- Check the measurement by connecting a resistor between the monitored network and the earth:
  - When the resistor value is alarm threshold +20%, no alarm is generated.
  - Then, when the resistor which value is alarm threshold -20%, an alarm is generated.

This test must be done offline and installation under test disconnected.

Check that the alarm relay toggles according to the resistance used for the test.

### Using Modbus/98 protocol to perform Commissioning process


The IM400 implements a communication protocol that is compliant with the requirements of IEC60730-1:Annex H (SW Class B). Using this communication protocol in place of the standard Modbus interface helps provide a functional safe channel between the IMD and the system.

This gives the user the possibility to perform the validation of the IMD setup and commissioning procedure (Insulation Monitoring and Insulation Fault Detection Testing) by ensuring the values set on the IM400 are as expected (Modbus/98 Write function) and the values read from IM400 are reliable (according to Class B IEC 60730-1 annex H).

The protocol is defined as an add-on to the standard Modbus protocol (as defined in the Modbus Serial Line Protocol and Implementation Guide v1.02 from Modbus.org) using a custom function code: 98 (0x62).

Please refer to the dedicated Vigilohm IM400 – Modbus/98 protocol document for a detailed description of the protocol and implementation guide of the master driver.

The protocol relies on a session mechanism to enclose the communication in a safe structure, as described below:



Multiple Modbus/98 Read/Write operations can happen during an active session, but it is mandatory to close the session at the end of a given sequence.

**NOTE:** It is the responsibility of the master in the system to guarantee the sessions are closed correctly. A timeout set during the open session sequence allows you to automatically close a session after a given time.

Using this protocol provides the following features:

- **Data Integrity:** The use of the Modbus/98 protocol helps ensure the integrity of the data transmitted and processed by the IM400C across product and system failures, by using dedicated error management mechanisms embedded in the protocol
- **Communication Sync:** The use of the Modbus/98 protocol helps ensure the transmissions are sequential and in a valid time window
- **Secure Link:** The use of the Modbus/98 protocol helps ensure the master and slave devices have means of identifying both ends of the active communication session using unique tokens re-initialized at every session

Both protocols (standard and /98) can be used at the same time in IM400C, but in order to comply to all the functional safety standards requirements the system which integrates the IMD must implement the following configuration sequence (using Modbus/98 protocol):

	Register	Value	Comment
Lock standard Modbus	4000	1 (ON)	Read function is still active
Lock HMI with password	3014	0000-9999	Set password
	3015	1	Activate password protection
Lock Inhibition input	3000	2 (OFF)	Inhibition is still possible through Modbus/98 write @3035

**NOTE:** The parameters above are stored in non-volatile memory and are therefore persistent over a power cycle.

The IM400 cannot validate if the data it receives is correct and applicable to the system. It can only validate the integrity of the data received.

<i>NOTICE</i>
<b>INACCURATE DATA RESULTS</b>
Make sure the system sending the data is configured correctly and the data from the system is correct.
<b>Failure to follow these instructions can result in equipment damage.</b>

# Chapter 8

## Specifications

### Specifications

#### Type of Installation to Be Monitored

Characteristic		Values
AC or mixed AC/DC IT systems <sup>(1)</sup>	Phase-to-phase voltage with IM400 connected to neutral	≤ 830 Vac <sup>(1)(2)</sup> or ≤ 1,700 Vac <sup>(3)</sup> ≤ 1,500 Vac <sup>(5)</sup>
	With IM400 connected to phase	≤ 480 Vac <sup>(1)(2)</sup> or ≤ 1,000 Vac <sup>(3)</sup> or ≤ 2,600 Vac <sup>(5)</sup>
	Frequency	45...440 Hz
AC	Phase-to-phase voltage with IM400 connected to neutral	≤ 33 kVac <sup>(6)</sup>
DC or rectified systems	Line voltage	< 480 Vdc <sup>(1)(2)</sup> or ≤ 1,200 Vdc <sup>(4)</sup> ≤ 1,500 Vdc <sup>(5)</sup>
<p>(1) When the insulation monitor is linked to a non-insulated inverter, it is necessary to take into account the DC voltage limit rather than the AC limit.</p> <p>(2) IM400 directly connected to the power system.</p> <p>(3) IM400 used with IM400-1700 or PHT1000 voltage adaptors.</p> <p>(4) 1000 Vdc with IM400-1700 and 1200 Vdc with PHT1000.</p> <p>(5) IM400 used with IM400VA2 voltage adaptors.</p> <p>(6) IM400THR used with P1N ground adaptor and compatible Schneider Electric voltage transformer.</p>		

### Electrical Characteristics

Characteristic		Values	
Range for insulation resistance readings		10 Ω...10 MΩ	
Range for capacitance readings		0.01...500 μF (2,000 μF for photovoltaic applications with IM400-1700 voltage adaptor) (5,500 μF for photovoltaic applications with IM400VA2 voltage adaptor)	
Insulation fault signaling	Number of thresholds	2 (protected password)	
	Threshold settings	Insulation alarm	0.04...500 kΩ
		Preventive insulation alarm	1 kΩ...1 MΩ
Hysteresis on the thresholds of insulation alarm and preventive insulation alarm		<ul style="list-style-type: none"> <li>● Setting threshold when the insulation alarm triggers</li> <li>● Setting threshold +20% when the insulation alarm releases</li> </ul>	
Time delay for signaling		0...7,200 s	
Dielectric strength		4000 Vac / 5500 Vdc 7.3 kV impulse	
Auxiliary supply voltage	IM400/IM400C/IM400THR	100...440 Vac 50/60/400 Hz 100...440 Vdc	
	IM400L/IM400LTHR	24...48 Vdc	
Auxiliary supply voltage tolerances		+/-15 %	
Monitored system voltage tolerances	IM400 directly connected	+5%	
	IM400 used with IM400-1700 or IM400VA2	+15%	

Characteristic		Values	
Maximum device consumption	IM400/IM400C/IM400THR	25 VA / 10 W	
	IM400L/IM400LTHR	10 W	
Measurement voltage	IM400/IM400C/IM400L	15 Vp, 33 Vp, 120 Vp	
	IM400THR/IM400LTHR	20 Vdc, 40 Vdc, 60 Vdc, 80 Vdc	
Measurement current	IM400/IM400C/IM400L	375 $\mu$ Ap, 825 $\mu$ Ap, 3 mAp	
	IM400THR/IM400LTHR	469 $\mu$ Adc, 940 $\mu$ Adc, 1.56 mAdc, 2.48 mAdc	
Fault locating current (IM400/IM400C/IM400L)		3.75 mAp	
Extraneous DC voltage Ufg		506 V	
Device operating test		Self-test / manual test	
Internal impedance	At 50/60/400 Hz	40 k $\Omega$	
Internal resistance Ri of the measuring circuit		40 k $\Omega$	
Output contact	Quantity	2 (standard and failsafe)	
	Type of contact	SPDT one changeover contact	
	Operating principle	N/O N/C operation	
	Electrical endurance	30,000 cycles	
	Breaking capacity	250 Vac	3 A
		48 Vdc	1 A, 10 mA minimum load
Minimum switching load	24 Vac/dc	2 mA	
Injection inhibition (voltage supplied by IM400)	Voltage	24 Vdc	
	Current	5 mA	
Installation category		300 V/OVC III, degree of pollution 2	
		600 V/OVC II, degree of pollution 2	

### Mechanical Characteristics

Characteristic		Value
Weight		0.75 kg
Thermoplastic case	Mounting	Flush mount or on grid
Degree of protection	Front	IP54
	Back	IP20

### Other Characteristics

Characteristic		Value	
Temperature range	For operation	-25...+55 °C (K55 )	
		With IM400-1700 voltage adaptor and 230 V $\pm$ 15 % auxiliary supply.	-25...+65 °C
		With IM400VA2 voltage adaptor and 230 V $\pm$ 15 % auxiliary supply.	-25...+70 °C
	For storage	-40...+70 °C	
Climatic conditions <sup>(1)</sup>		IEC 60068	
Use		Indoors	
Altitude		Up to 3000 m	
Degree of pollution		2	
<b>(1)</b> Suitable for use in all climates: <ul style="list-style-type: none"> <li>• Damp heat, equipment not operating (IEC 60068-2-30)</li> <li>• Damp heat, equipment operating (IEC 60068-2-56)</li> <li>• Salt mist (IEC 60068-2-52)</li> </ul>			

Characteristic		Value
Overvoltage category		300 V / OVCI, 600 V / OVCI
Standards	Product	IEC 61557-8
	Safety	UL 61010-1, CAN/CSA-C22.2 No. 610101
	Installation	IEC 60364-4-41
	Output contact	IEC 61810-2
<b>(1)</b> Suitable for use in all climates: <ul style="list-style-type: none"> <li>• Damp heat, equipment not operating (IEC 60068-2-30)</li> <li>• Damp heat, equipment operating (IEC 60068-2-56)</li> <li>• Salt mist (IEC 60068-2-52)</li> </ul>		

### Electrical Characteristics

**NOTE:** This table is applicable for IM400-1700 voltage adaptor.

Characteristic		Value
Dielectric strength		15.4 kV impulse
Measurement current	Variable	30 $\mu$ Ap, 60 $\mu$ Ap, 220 $\mu$ Ap
Extraneous DC voltage Ufg		1,150 Vdc
Internal impedance	At 50/60/400 Hz	430 k $\Omega$
Internal resistance Ri of the measuring circuit		430 k $\Omega$





## I

### **Insulation Alarm**

The insulation alarm is triggered when the insulation level on the monitored network goes below the configured threshold.

## P

### **Preventive Insulation Alarm**

The preventive insulation alarm is triggered when the insulation level on the monitored network goes below the configured threshold – this value cannot be set lower than the Insulation Alarm threshold.

## T

### **Transient Fault**

The transient fault appears when the insulation alarm triggers and the insulation level on the monitored network has gone back above the configured threshold without user acknowledging the insulation alarm.